

**TM8100** mobiles  
**TM8200** mobiles

# Accessories Manual



MMA-00012-02  
Issue 02  
August 2005

# Tait Contact Information

---

## Tait Radio Communications Corporate Head Office

Tait Electronics Ltd  
P.O. Box 1645  
Christchurch  
New Zealand

For the address and telephone number of regional offices, refer to the TaitWorld website:

Website: <http://www.taitworld.com>

## Technical Support

For assistance with specific technical issues, contact Technical Support:

E-mail: [support@taitworld.com](mailto:support@taitworld.com)

Website: <http://support.taitworld.com>



### To our European customers:

Tait Electronics Limited is an environmentally responsible company which supports waste minimization and material recovery. The European Union's Waste Electrical and Electronic Equipment Directive requires that this product be disposed of separately from the general waste stream when its service life is over. Please be environmentally responsible and dispose through the original supplier, your local municipal waste "separate collection" service, or contact Tait Electronics Limited.

# Contents

---

<b>Tait Contact Information</b> . . . . .	<b>2</b>
<b>Preface</b> . . . . .	<b>7</b>
Scope of Manual . . . . .	7
Enquiries and Comments . . . . .	7
Updates of Manual and Equipment . . . . .	7
Copyright . . . . .	7
Disclaimer . . . . .	7
Associated Documentation . . . . .	8
Publication Record . . . . .	8
Alert Notices . . . . .	9
Abbreviations . . . . .	10
<b>1 Safety and Servicing Information</b> . . . . .	<b>11</b>
1.1 Personal Safety . . . . .	11
1.2 Equipment Safety . . . . .	11
1.3 Identifying Screw Types . . . . .	12
1.4 Regulatory Information . . . . .	14
1.5 PCB Information . . . . .	14
<b>2 TMAA01-01 Line-Interface Board</b> . . . . .	<b>15</b>
2.1 Operation . . . . .	15
2.2 Configuring the Line-Interface Board . . . . .	15
2.3 Installing the Line-Interface Board . . . . .	19
2.4 Programming Information . . . . .	22
2.5 Interface Specification . . . . .	23
2.6 Line-Interface Board Application . . . . .	24
2.7 Line-Interface Board Specifications . . . . .	25
2.8 Circuit Description . . . . .	27
2.9 PCB Information . . . . .	29
<b>3 TMAA01-02 RS-232 Board</b> . . . . .	<b>35</b>
3.1 Operation . . . . .	35
3.2 Installing the RS-232 Board . . . . .	36
3.3 Interface Specification . . . . .	38
3.4 PCB Information . . . . .	39

<b>4</b>	<b>TMAA01-05 Options-Extender Board</b>	<b>43</b>
4.1	Changing the Options-Extender Links	43
4.2	Installing the Options-Extender Board	45
4.3	Interface Specification	47
4.4	PCB Information	49
<b>5</b>	<b>TMAA02-02 DTMF Microphone</b>	<b>53</b>
5.1	Installation	53
5.2	Adjustment	54
5.3	Radio Programming	54
5.4	Interface Specification	54
5.5	Circuit Description	55
<b>6</b>	<b>TMAA02-06 Support Kit for Concealed &amp; Dynamic Microphones</b>	<b>57</b>
6.1	Installation	57
6.2	Radio Programming	58
6.3	Interface Specification	59
6.4	PCB Information	60
<b>7</b>	<b>TMAA02-07 Concealed Microphone</b>	<b>65</b>
7.1	Installation	65
7.2	Radio Programming	67
<b>8</b>	<b>TMAA02-08 Keypad Microphone</b>	<b>69</b>
8.1	Operation	69
8.2	Installation	71
8.3	Radio Programming	72
8.4	Interface Specification	73
8.5	Circuit Description	73
8.6	PCB Information	74
<b>9</b>	<b>TMAA03-02 Security Bracket</b>	<b>79</b>
9.1	Installing the Security Bracket and Radio	80
9.2	Installation Planning	80
9.3	Removing a Radio from the Security Bracket	81
9.4	Replacing the Radio in the Security Bracket	81
9.5	Disassembling the Security Bracket	81
9.6	Re-Ordering Extra Parts	82

<b>10</b>	<b>Installing a Remote Kit</b>	<b>83</b>
10.1	Installation	83
10.2	Circuit Description	89
10.3	Servicing the Remote Kit Parts	90
10.4	PCB Information	92
<b>11</b>	<b>Installing an Enhanced Remote Kit</b>	<b>99</b>
11.1	Installation	99
11.2	Circuit Description	105
11.3	Servicing the Remote Control-Head Installation Parts	106
11.4	PCB Information	108
<b>12</b>	<b>TMAA04-04 Crossband Linking Cable</b>	<b>115</b>
12.1	Installation	115
12.2	Radio Programming	115
12.3	Operational Testing	117
12.4	Interface Specification	117
12.5	PCB Information	118
<b>13</b>	<b>TMAA04-05 Ignition Sense Kit</b>	<b>121</b>
13.1	Installation	121
13.2	Radio Programming	121
<b>14</b>	<b>TMAA10-01 Desktop Microphone</b>	<b>123</b>
14.1	Operation	123
14.2	Installation	123
14.3	Adjustment	124
14.4	Interface Specification	124
14.5	Circuit Description	125
<b>15</b>	<b>TMAA10-02 Handset</b>	<b>127</b>
15.1	Installation	127
15.2	Radio Programming	129
15.3	Interface Specification	130
<b>16</b>	<b>TMAA10-03 and TMAA10-06 High-Power Remote Speakers</b>	<b>131</b>
16.1	Installation	131
<b>17</b>	<b>TMAA10-04 Remote PTT Kit and TMAA10-05 Hands-Free Kit</b>	<b>133</b>
17.1	VOX Operation (TMAA10-05 Hands-Free Kit)	133

17.2 Installation . . . . .	134
17.3 Radio Programming for the TMAA10-04 Remote PTT Kit. . . . .	135
17.1 Radio Programming for the TMAA10-05 Hands-Free Kit . . . . .	136
17.1 Interface Specification . . . . .	136
17.2 Circuit Description . . . . .	137
17.3 PCB Information . . . . .	138
<b>18 TOPA-SV-024 Test Unit . . . . .</b>	<b>139</b>
18.1 Test Equipment Setup. . . . .	139
18.2 Operation. . . . .	141
18.3 PCB Information . . . . .	143
<b>Tait General Software Licence Agreement . . . . .</b>	<b>145</b>

# Preface

---

## Scope of Manual

This manual contains information on installing, operating and servicing accessory products for TM8100 and TM8200 radios.

## Enquiries and Comments

If you have any enquiries regarding this manual, or any comments, suggestions and notifications of errors, please contact Technical Support (refer to [“Tait Contact Information”](#) on page 2).

## Updates of Manual and Equipment

In the interests of improving the performance, reliability or servicing of the equipment, Tait Electronics Ltd reserves the right to update the equipment or this manual or both without prior notice.

## Copyright

All information contained in this manual is the property of Tait Electronics Ltd. All rights are reserved. This manual may not, in whole or in part, be copied, photocopied, reproduced, translated, stored, or reduced to any electronic medium or machine-readable form, without prior written permission from Tait Electronics Ltd.

All trade names referenced are the service mark, trademark or registered trademark of the respective manufacturers.

## Disclaimer

There are no warranties extended or granted by this manual. Tait Electronics Ltd accepts no responsibility for damage arising from use of the information contained in the manual or of the equipment and software it describes. It is the responsibility of the user to ensure that use of such information, equipment and software complies with the laws, rules and regulations of the applicable jurisdictions.

## Associated Documentation

MMA-00002-0X TM8100 Mobiles User's Guide

MMA-00003-0X TM8200 Mobiles User's Guide

MMA-00005-0X TM8100/TM8200 Mobile Radio Service Manual

All available TM8000 product documentation is provided on the TM8000 Product Support CD, product code TMAA20-01. Updates may also be published on the Tait support website.

## Publication Record

Issue	Publication Date	Description
1.00	September 2003	first release
2.00	December 2003	added information about the TMAA01-01 line-interface board, TMAA02-06 support kit for concealed and dynamic microphones, TMAA10-02 handset and TMAA10-03 high-power remote speaker
01	December 2004	<ul style="list-style-type: none"><li>■ changed product code to MMA-00012-01</li><li>■ added information about the TMAA02-07 concealed microphone, TMAA02-08 keypad microphone, TMAA03-02 security bracket, installing a remote control head, TMAA10-05 hands-free kit and TMAA10-06 high-power remote speaker (for 40W/50W radios)</li></ul>
02	June 2005	<ul style="list-style-type: none"><li>■ added information about the TMAA01-02 RS-232 board, TMAA02-06 support kit for a concealed microphone, TMAA03-02 security bracket and installing an enhanced remote kit.</li><li>■ updated information about the TMAA01-01 line-interface board and installing a remote control head.</li><li>■ corrected errors in the TMAA01-05 options extender board (<a href="#">Table 4.4</a>), TMAA02-02 DTMF microphone (<a href="#">Section 5.2</a>).</li></ul>

## Alert Notices

Within this manual, four types of alerts are given to the reader: warning, caution, important and note. The following paragraphs illustrate each type of alert and its associated symbol.



***Warning!!*** This alert is used when there is a potential risk of death or serious injury.



***Caution*** This alert is used when there is the risk of minor or moderate injury to people.



***Important*** This alert is used to warn about the risk of equipment damage or malfunction.



***Note*** This alert is used to highlight information that is required to ensure that procedures are performed correctly.

## Abbreviations

<b>Abbreviation</b>	<b>Description</b>
AF	Audio Frequency
ALC	Automatic Level Control
CD	Compact Disk
CMOS	Complementary Metal Oxide Semiconductor
DTMF	Dual Tone Multiple Frequency
DIP	Dual In-Line Package
ESD	Electrostatic Discharge
IC	Integrated Circuit
IPN	Internal Part Number
LED	Light Emitting Diode
NB	Narrow Bandwidth (12.5kHz channel spacing)
PABX	Private Automatic Branch Exchange
PCB	Printed Circuit Board
PGA	Programmable-Gain Amplifier
PSTN	Public Switched Telephone Network
PTT	Press-To-Talk
PSTN	Public Switched Telephone Network
RF	Radio Frequency
SPI	Serial Peripheral Interface
WB	Wide Bandwidth (25kHz channel spacing)

# 1 Safety and Servicing Information

---

This chapter contains general information about safety and servicing procedures when working with TM8000 radios. While many TM8000 accessories plug into external radio interfaces, some accessories are fitted inside the radio. Refer to the service manual for detailed disassembly and reassembly information.

## 1.1 Personal Safety

### Explosive Environments



**Warning!!** Do not operate equipment near electrical blasting caps or in an explosive atmosphere. Operating the equipment in these environments is a definite safety hazard.

### Proximity to RF Transmissions

Do not operate the transmitter when someone is standing within 0.9m (35 inches) of the antenna. Do not operate the transmitter unless you have checked that all RF connectors are secure.

### High Temperatures

The bottom surface of the radio and heatsink fins can become hot during prolonged operation. Do not touch these parts of the radio.

## 1.2 Equipment Safety

### ESD Precautions




**Important** This equipment contains devices which are susceptible to damage from static discharges. You must handle these devices carefully and according to the procedures described in the manufacturers' data books.

Purchase an antistatic bench kit from a reputable manufacturer and install and test it according to the manufacturer's instructions. Figure 1.1 shows a typical antistatic bench set-up.

You can obtain further information on antistatic precautions and the dangers of electrostatic discharge (ESD) from standards such as ESD S4.1-1997 (revised) or BS EN 100015-4 1994. The Electrostatic Discharge Association website is <http://www.esda.org/>.

**Figure 1.1** Typical antistatic bench set-up



## Antenna Load

This radio has been designed to operate safely under a wide range of antenna loading conditions. However, the radio should always be operated with a suitable load to prevent damage to the transmitter output power stage.

## 1.3 Identifying Screw Types

### Torx Recess Head Screws

Torx recess head screws are the standard type of screw used in TM8000 equipment, although Pozidriv head screws are also used in a few special applications.


The Torx recess head has the advantage of improved screwdriver tip location, reducing the chances of screw head damage caused by the driver tip rotating within the recess. In addition, using a ball-tip Torx screwdriver allows you to drive a Torx head screw with the driver on a slight angle, which can be useful in situations where access is restricted.

It is important that you use the correct Torx screwdriver tip:

- M2.5 screws - T8
- M3 screws - T10
- M4 screws - T20.

Figure 1.2 below shows a typical Torx recess head screw (the actual hardware may differ slightly from this illustration due to variations in manufacturing techniques).

**Figure 1.2 Identifying Torx screws**



## Allen UNC Screws

Allen 4-40 UNC thread screws are used in some locations in the TM8000 radio and cannot be interchanged with M3 screws.

## Pozidriv and Philips Screws

Both Pozidriv and Philips head screws are used on certain TM8000 accessories. It is important that you use the correct type and size screwdriver to avoid damaging screw heads.


It is particularly important that you do not use Philips screwdrivers on Pozidriv screw heads as the tapered driving flutes of the Philips screwdriver do not engage correctly with the parallel-sided slots in the Pozidriv screw head. This can result in considerable damage to the screw head if the screwdriver tip turns inside the recess.



**Note** If you find you need excessive downwards pressure to keep the screwdriver tip in the Pozidriv screw head, you are probably using the wrong type or size screwdriver.

Figure 1.3 on the following page shows the main differences between typical Pozidriv and Philips screw heads and screwdriver tips (actual hardware may differ slightly from these illustrations due to variations in manufacturing techniques).

**Figure 1.3 Identifying Pozidriv and Philips screws and screwdrivers**



## 1.4 Regulatory Information

Any modifications you make to this equipment which are not authorised by Tait Electronics Ltd may invalidate your compliance authority's approval to operate the equipment.


## 1.5 PCB Information

All PCBs are identified by a unique 10 digit IPN (internal part number) which is printed onto the PCB (usually on the top side), as shown in the example below:

**226-00124-03**

The last two digits of this number define the issue status, which starts at 01 and increments through 02,03, 04, etc. as the PCB is updated. If the PCB information contained in a section of this manual does not match the PCB number printed on your board, contact Technical Support (refer to "[Tait Contact Information](#)" on page 2).

## 2 TMAA01-01 Line-Interface Board



The TMAA01-01 line-interface board provides both audio and digital interfaces for a variety of systems. The interfaces available are:

- an isolated 600 $\Omega$  audio interface which is capable of both simplex operation on a two-wire system, or duplex operation on a four-wire system
- a keying interface which allows for two-wire keying or single line bi-directional keying
- a variable delay timer
- a logic sense control.

The line-interface board fits inside the radio in the options cavity and is connected to the main PCB by the internal options loom. The high-density 15-way D-range connector mounted on the line-interface board fits through the external options connector hole provided in the radio chassis.



### **Important**

This kit does not meet the IP54 protection standard. Care must be taken when a radio with a TMAA01-01 line-interface board kit installed is being operated in an environment where there is water, dust or other environmental hazards.

### 2.1 Operation

One of the control head function keys may be programmed to toggle the line-interface board on and off. When the function key LED is glowing, the line-interface board is on and when the LED is off, the line-interface board is off.

Refer to [“Programming Information” on page 22](#) for information on the radio programming procedure.

### 2.2 Configuring the Line-Interface Board




### **Important**

This equipment contains devices which are susceptible to damage from static discharges. Refer to [“ESD Precautions” on page 11](#) for more information.

## 2.2.1 Adjustment Points on the Line-Interface Board

The following table describes the line-interface adjustment points. Adjustments are made by setting the DIP switches on S1 to either “on” or “off” and by three variable resistors (RV1, RV2 and RV3).


**Table 2.1** Line-interface board adjustment points

 <p>line-interface board top side</p>	Function	Selection 1	Selection 2
	two-wire audio interface	DIP1 on	DIP2 off
	four-wire audio interface	DIP1 off	DIP2 on
	busy/gate = busy	DIP3 on	DIP4 off
	busy/gate = rx-gate	DIP3 off	DIP4 on
	busy/gate logic (active high)	DIP5 on	DIP6 off
	busy/gate logic (active low)	DIP5 off	DIP6 on
	bi-directional keying line	DIP7 on	
	two-wire keying	DIP 7 off	
	enable gate/keying delay	DIP8 on	
	gate/keying delay	adjust RV1	
	audio line out level	adjust RV2	
	audio line in level	adjust RV3	
	time delay range	W1 open	

## 2.2.2 Test Equipment Setup

The following diagram shows the setup of the test equipment used when adjusting RV1, RV2 and RV3.

**Figure 2.1 Line-interface test equipment setup**



### 2.2.3 Configuration Procedure

The line-interface board configuration must be completed before the board is installed in the radio, as the top side of the line-interface board is not accessible once the board is screwed to the radio lid. To configure the line-interface board, carry out the following steps.

1. Program the radio in which the line-interface board is being installed with default line-interface test settings. The default test settings are explained in the following tables.



**Note** A general description of IOP\_GPIO lines used with the line-interface board is given in [Table 2.6 on page 22](#).

**Table 2.2 Line-interface default test settings in the Programmable I/O form, Digital tab**

Pin	Direction	Label	Action	Active	Debounce	Signal State	Mirrored
IOP_GPIO1	Input	None	External PTT 1	Low	60	None	None
IOP_GPIO2	Output	0	No Action	Low	None	None	None
IOP_GPIO3	Output	BUSY	Busy Status	High	None	None	None
IOP_GPIO4	Output	FKEY	F1 Key Status <sup>a</sup>	Low	None	Latching	None

- a. One of the four control head function keys may be selected to control the line-interface AUX line, which turns the line-interface board on and off. For the associated LED to reflect the status of the line-interface board, the Function Key Action field on the Key Settings form must be set to Action Digital Output Line.

**Table 2.3 Line-interface settings in the Programmable I/O form, Audio tab**

Rx/PTT Type	Tap In	Tap In Type	Tap In Unmute	Tap Out	Tap Out Type	Tap Out Unmute
Rx	None	A-Bypass In	On PTT	R7	D - Split	Busy Detect
EPTT1	T5	A-Bypass In	On PTT	None	C-Bypass 0	On PTT

**Table 2.4 Line-interface settings in the PTT form, External PTT (1) tab**

Field	Setting	
Advanced PTT	PTT Transmission Type	Voice
	Audio Source	Audio Tap In

2. Set the DIP switches on the line-interface board (S1) to the following default test settings:
  - DIP1 on (two-wire audio interface)
  - DIP2 off
  - DIP3 off
  - DIP4 on (busy/gate = rx-gate)
  - DIP5 on (busy/gate logic active high)
  - DIP6 off
  - DIP7 off (two-wire keying)
  - DIP8 off (time delay disabled).
3. Disassemble the radio in order to gain access to the options cavity. For detailed disassembly instructions, refer to the disassembly procedure in the service manual.



**Note** When installing the internal options loom, take care that it is folded in the way shown in [Figure 2.2](#).

Connect the internal options loom between SK2 on the line-interface board and SK102 on the radio's main PCB.

4. Set up the test equipment shown in [Figure 2.1](#), and follow the adjustment procedure for RV1, RV2 and RV3 described in the following section.

## 2.2.4 Adjusting RV1, RV2 and RV3

### Setting the Keying Time Delay (RV1)

The keying time delay circuit is used to prevent the burst of noise occurring before a mobile is able to mute the audio when the carrier signal disappears. The keying time delay is used in conjunction with the keying signal (SK1 pin 1).

Set DIP8 on, and adjust RV1 for the required time delay. Rotate RV1 clockwise to increase the delay, and counterclockwise to reduce the delay.



**Note** If the W1 link is fitted, the maximum time delay available is reduced from 5 seconds to approximately 2.5 seconds.

### Setting the Line Output Level (RV2)

Monitor the line output (SK1 pins 14 and 15) and apply an on-channel signal from the RF signal generator at an output level of -47 dBm, modulated to 60% of system deviation, at 1 kHz AF.

Adjust the RV2 for a line output level of -10 dBm.

### Setting the Line Input Level (RV3)

Apply a line input signal of -10 dBm and key the transmitter.

- For a two-wire configuration, apply the line input signal to pins 14 and 15 on SK1.
- For a four-wire configuration, apply the line input signal to pins 4 and 10 on SK1.

Adjust RV3 until 60% of system deviation at 1 kHz is achieved.

## 2.3 Installing the Line-Interface Board



**Note** The line-interface board link options must be set before the board is installed in the radio, as the top side of the line-interface board is not accessible once the board is screwed to the radio lid.

### 2.3.1 Parts Required

The following table describes the parts required to install a line-interface board in a radio. The parts marked with an asterisk (★) are not shown in [Figure 2.2](#) and are used to connect to the radio's external options connector.

**Table 2.5** Line-interface installation parts required

Quantity	Internal Part Number	Description	Figure 2.2 Reference
1	362-01111-XX <sup>a</sup>	foam seal	③
1	362-01108-XX <sup>a</sup>	cover seal	⑪
2	347-00011-00	4-40x3/16 screws	⑫
2	354-01043-00	screw-lock fasteners	⑦
6	349-02062-00	M3x8 screws	⑨
★1	240-00010-80	D-range plug	—
★1	240-06010-29	D-range hood	—

a. Contact Technical Support for the exact IPN.

## 2.3.2 Installation Procedure

1. Disassemble the radio in order to gain access to the options cavity.  
For detailed disassembly instructions, refer to the disassembly procedure in the service manual.

The circled numbers in the following instructions refer to items in the diagram on the previous page.

2. Remove the top cover and lid ① from the radio to access the options cavity.
3. Remove the external options connector bung ②, if it is fitted.
4. On the inside of the radio lid place the foam seal ③ over the external options connector cavity ④.
5. With the top side of the line-interface board ⑤ facing the radio lid, guide the external options connector ⑥ (the D-range connector on the line-interface board) into the external options connector cavity.
6. Screw the external options connector to the radio lid using the two screw-lock fasteners ⑦.

Tighten the fasteners to a torque of 0.9N·m (8lbf·in).



**Important** The external options connector screw-lock fasteners must be tightened correctly before screwing the line-interface board onto the mounting posts ⑧.

7. Screw the line-interface board to the mounting posts on the radio lid using six M3x8 self-tapping screws ⑨.


Tighten the M3x8 screws to a torque of 1.9N·m (17lbf·in)



**Important** For the line-interface board to be installed correctly in the radio's options cavity, the internal options connector loom ⑩ must be looped in the way shown in [Figure 2.2](#).

8. Plug the unattached end of internal options connector loom ⑩ into the internal options connector on the radio main PCB.
9. Refit the radio lid and top cover to the radio and screw the external options cover seal ⑪ over the external options connector, using the two 4-40x3/16 screws ⑫.

**Figure 2.2 Installing the line-interface board**



## 2.4 Programming Information

The lines from the radio's internal options connector that are used by the line-interface board are IOP\_GPIO1 to IOP\_GPIO4. The behaviour of these lines is configured in the Programmable I/O and PTT forms of the programming application. Refer to the online help of the programming application for more information.

The [Table 2.6](#) explains the required input and output line-interface connections.

**Table 2.6** Line-interface input and output connections

Radio Signal	Function	Comments
GPIO1	PTT FROM OPT	This signal causes the radio to transmit. This normally requires External PTT1 to be set up in the Digital tab of the Programmable I/O form and the External PTT (1) tab of the PTT form.
GPIO2	Busy/Gate	This active high signal allows connection to the Busy/Gate output signal. If this is not used, the Action field is set to No Action and the Active field is set to Low.
GPIO3	Busy/Gate (Keying Line)	This active high signal allows connection to the Busy/Gate output signal. This signal also allows the single line keying functionality.
GPIO4	AUX	This allows the line-interface board to be disabled. One of the four control head function keys is selected to control this AUX line.  For the associated LED to reflect the status of the line-interface board, the Function Key Action field on the Key Settings form must be set to Action Digital Output Line.

## 2.5 Interface Specification


The following tables summarize the signals used for the line-interface board on the internal options connector (SK2 on the line-interface board) and the external options connector (SK1 on the line-interface board).

**Table 2.7 Internal options connector (SK2)—pins and signals**

	Pin	Radio Signal	Line-Interface Signal	Description
 <p>top view</p>	1	13V8_SW	13V8 FROM RADIO	switched 13V8 supply from the radio
	2	AUD_TAP_OUT	AUDIO TAP OUT	Programmable tap point out of the receive or transmit audio chain.
	3	AGND	AGND	analogue ground
	4	AUX_MIC_AUD	—	not connected
	5	RX_BEEP_IN	—	not connected
	6	AUD_TAP_IN	AUD_TAP_IN	Programmable tap point into the receive or transmit audio chain.
	7	RX_AUD	—	not connected
	8	RSSI	—	not connected
	9	IOP_GPIO1	PTT FROM OPT	IOP_GPIO1 from the radio 3V3 logic level, 5V tolerant
	10	IOP_GPIO2	SECONDARY BUSY	IOP_GPIO2 from the radio 3V3 logic level, 5V tolerant
	11	IOP_GPIO3	BUSY	IOP_GPIO3 from the radio 3V3 logic level, 5V tolerant
	12	IOP_GPIO4	AUX	IOP_GPIO4 from the radio 3V3 logic level, 5V tolerant
	13	IOP_GPIO5	GPIO5	IOP_GPIO5 from the radio 3V3 logic level, 5V tolerant
	14	IOP_GPIO6	—	not connected
	15	IOP_GPIO7	—	not connected
	16	DGND	AGND	analogue ground
	17	IOP_RXD	RXD	asynchronous serial port - receive data
	18	IOP_TXD	TXD	asynchronous serial port - transmit data

**Table 2.8 External options connector (SK1—pins and signals**


Pin	Signal	Description
1	KEYING	signal line keying
2	RS-422/RS-232	serial data TX-/RS-232 TXD
11	RS-422	serial data TX+
3	PTT-IN	bi-directional keying input
4	4W_LINE_IN -	4-wire line in negative
10	4W_LINE_IN +	4-wire line in positive
5	RS-422/RS-232	serial data RX+/RS-232 RXD
6	RS-422	serial data RX-
7	GND	ground
8	—	not connected
9	13V8 FROM RADIO	switched 13.8V supply from the radio
12	BUSY/GATE	busy or receiver gate output. 5V CMOS logic level.
13	—	not connected
14	4W_LINE_OUT -	4-wire line out negative or 2-wire line in/out negative
15	4W_LINE_OUT +	4-wire line out positive or 2-wire line in/out positive



## 2.6 Line-Interface Board Application

The following diagram shows the control of two radios operated together, crossband or repeater linked.

**Figure 2.3 Two radios connected as a repeater/crossband link**



## 2.7 Line-Interface Board Specifications

Input Voltage	10.8V to 16VDC
Operating Temperature Range	-10°C to +60°C ambient
DC Input Current	<40mA total (+13.8V supply)
Line Input Sensitivity (60% deviation)	-20dBm to +6dBm (600Ω)
Line Output Level (60% deviation)	-20dBm to +6dBm (600Ω)
Line Impedance	600Ω
Return Loss (300Hz to 3kHz)	>20dB relative to 600Ω
Line Output Filter Response (stopband)	
2 pole	-12dB/octave, f >4kHz
6 pole	-36dB/octave, f >4kHz

### 2.7.1 Radio With Line-Interface Board: Receiver + Line Output

Receiver Frequency Response*	
Receiver Processed Bandwidth	300Hz to 3kHz (standard 400Hz to 3kHz (CTCSS)
Response	+1, -3dB relative to -6dB/octave
Receiver Unprocessed	+1, -3dB (300Hz to 3kHz)
*relative to 1kHz, 60% deviation	
Test Signal	-46dBm RF*, 0dBm line output, audio tap T4 *60% deviation at 1kHz
Signal-to-Noise Ratio	
Narrow Bandwidth	>40dB
Wide Bandwidth	>43dB
Mute Ratio	>60dB
Distortion*	
Narrow Bandwidth	<4%
Wide Bandwidth	<4%
*30kHz bandwidth distortion meter	

## 2.7.2 Radio With Line-Interface Board: Receiver + Line Input

---

### Transmitter Frequency Response\*

Bandwidth	300Hz to 3kHz
Response	+1, -3dB relative to -6dB/octave

\*relative to 1 kHz, 20% deviation, below limiting

---

Test Signal	0dBm line input*, audio tap T1
	*60% deviation at 1 kHz

---

### Signal-to-Noise Ratio\*

Narrow Bandwidth	>40dB
Wide Bandwidth	>43dB

\*demodulated, filtered 300Hz to 3kHz and de-emphasised 750 $\mu$ s rms

---

Mute Ratio	>60dB
------------	-------

---

Distortion*	<3%
-------------	-----

\*demodulated, filtered 15kHz low pass

---

## 2.8 Circuit Description

### 2.8.1 Audio Interface

When the line-interface board is used for repeater applications, the audio passed between the two radios must be of such a level that the message is able to be repeated intelligibly. The audio interface is therefore capable of handling a wide range of input and output levels (-20 to +6dBm). The audio interface is also capable of using either a two- or four-wire isolated interface formats, which are selectable using S1.

The input to the line driver IC (U5) is the AUDIO TAP OUT line from the radio. This line is a software-programmable tap point which can be chosen from various audio signals available within the radio and is coupled through a capacitor into the audio line out level control (RV2). This variable resistor is AC coupled into the line driver (U5) which is used in a bridged-output format, with gain set to provide the necessary 21 dB gain.

The resistors on the output of the line driver provides the necessary 600 $\Omega$  terminating impedance, but also cause a 50% loss of signal. This is compensated for by the higher-than-necessary gain of the line driver. Line out protection is provided by two zener diodes, and the transformer (T1) provides isolation.

The audio interface is capable of using a two- or four-wire interface, so a tap is taken from one side of the balanced line out and is feed directly into the line input level control (RV3). When using a four-wire interface, the signal comes in through a second isolation transformer, T2. T2 is terminated with 600 $\Omega$  and also acts as a voltage divider. This means that the signal level at RV3 will be identical to the level at RV3 when using a two-wire interface.

To achieve the required output level the non-inverting AC amplifier (U7) has a gain of 10, which provides the necessary 13dB of gain. The output of the amplifier is AC coupled into the AUDIO\_TAP\_IN line (pin 6 of SK2).

### 2.8.2 Logic Interface

The line-interface board is able to provide simple interface solutions with other radios. Logic is used to control keying of both radios as well as providing time delays to prevent squelch or cycling problems. The logic uses gates rather than discrete components.

The choice of which input controls BUSY/GATE can be selected using switches 3 and 4 of S1, while the sense of BUSY/GATE (pin 12 of SK1) can be selected using switches 5 and 6. Switch 7 accommodates either a two-line keying system or a single bi-directional keying line.

The comparators (in U1) operate off a single sided regulated 5V supply.

U1 pins 2,4 and 5 provide receiver gate delay. Once the busy signal is not active, C4 charges through R12 and causes U4 to go low. Once charging exceeds the voltage at U1 pin5. This also locks out the keying state until this delay has occurred (U6 pin 5).

### **2.8.3 Data Communication**

The Line Interface circuitry is designed to provide RS-232 and RS-422 data communication. RS-232 is provided by U9, but if RS-422 is required, U9 is removed and replaced by U2 and U10. Also resistors R15,16,43 and 47 need to be fitted.

### **2.8.4 Power Supply**

The power supply for the line-interface board comes from the radio via the internal options connector and is a 13.8V switched supply. Digital logic components are used in the line-interface board so there is a 5V regulator provided.

Initially the 13.8V from the radio is filtered and used for the audio line driver (U5) with reference to analogue ground. This 13.8V is also used to supply the 5V regulator, which is filtered separately for either 5V digital or analogue devices. A simple voltage divider is used to provide a 2.5V half-rail for the digital and a 2.2V rail for the analogue sections.

## 2.9 PCB Information

### 2.9.1 TMAA01-01 Parts List (PCB IPN 220-65202-03)

Ref.	IPN	Description	Ref.	IPN	Description
C1	014-08100-03	Cap Tant SMD 10u 35v 20% D	R10	038-13100-10	RES 0603 100R 1% 1/10W
C2	015-26100-08	Cap Cer 0805 100n 10% X7r 50v	R11	038-14330-10	RES 0603 3k3 1% 1/10W
C3	014-07470-01	Cap Tant SMD 4u7 25v 10% B	R12	038-14560-00	RES 0603 5k6 5% 1/10W
C4	014-18100-05	Cap Tant SMD 10u 10v 10% A	R13	038-16330-10	RES 0603 330k 1% 1/10W
C5	015-26100-08	Cap Cer 0805 100n 10% X7r 50v	R14	038-16330-10	RES 0603 330k 1% 1/10W
C7	014-07470-01	Cap Tant SMD 4u7 25v 10% B	R15A	038-13680-00	RES 0603 680R 5% 1/10W
C8	018-14100-00	Cap 0603 1n 50v X7r ±10%	R16A	038-13120-00	RES 0603 120R 5% 1/10W
C9	018-14100-00	Cap 0603 1n 50v X7r ±10%	R17	038-13680-00	RES 0603 680R 5% 1/10W
C10	015-26100-08	Cap Cer 0805 100n 10% X7r 50v	R18	038-15100-10	RES 0603 10k 1% 1/10W
C12	015-26220-08	Cap 0805 220n 10% X7r 16v	R19	036-13270-00	RES 0805 270R 5% 1/8W
C13	015-26100-08	Cap Cer 0805 100n 10% X7r 50v	R20	038-15100-10	RES 0603 10k 1% 1/10W
C14	018-14100-00	Cap 0603 1n 50v X7r ±10%	R21	038-14330-10	RES 0603 3k3 1% 1/10W
C15	018-14100-00	Cap 0603 1n 50v X7r ±10%	R22	038-10000-00	RES 0603 0R
C16	014-06220-00	Cap Tant SMD 2.2Mf 50v	R23	038-15100-10	RES 0603 10k 1% 1/10W
C17	015-26220-08	Cap 0805 220n 10% X7r 16v	R24	038-14330-10	RES 0603 3k3 1% 1/10W
C18	016-08470-01	Cap Elec SMD 47uf 6*4 16v	R25	038-15100-10	RES 0603 10k 1% 1/10W
C19	018-15100-00	Cap 0603 10n 50v X7r ±10%	R26	038-15470-10	RES 0603 47k 1% 1/10W
C20	018-15100-00	Cap 0603 10n 50v X7r ±10%	R27	038-15820-10	RES 0603 82k 1% 1/10W
C21	014-07470-01	Cap Tant SMD 4u7 25v 10% B	R28	038-15470-10	RES 0603 47k 1% 1/10W
C22	018-15100-00	Cap 0603 10n 50v X7r ±10%	R29	038-16120-10	RES 0603 120k 1% 1/10W
C25	015-26220-08	Cap 0805 220n 10% X7r 16v	R30	038-15470-10	RES 0603 47k 1% 1/10W
C26	018-13150-00	Cap 0603 150p 50v NPO ±5%	R31	038-15470-10	RES 0603 47k 1% 1/10W
C27	015-26220-08	Cap 0805 220n 10% X7r 16v	R32	038-16120-10	RES 0603 120k 1% 1/10W
C28	015-26220-08	Cap 0805 220n 10% X7r 16v	R34	038-12560-00	RES 0603 56R 5% 1/10W
C29	018-15100-00	Cap 0603 10n 50v X7r ±10%	R35	038-14100-10	RES 0603 1k0 1% 1/10W
C30	018-15100-00	Cap 0603 10n 50v X7r ±10%	R36	038-15470-10	RES 0603 47k 1% 1/10W
C31	018-15100-00	Cap 0603 10n 50v X7r ±10%	R37	038-15100-10	RES 0603 10k 1% 1/10W
C32	018-15100-00	Cap 0603 10n 50v X7r ±10%	R38	038-15120-10	RES 0603 12k 1% 1/10W
C35	015-26220-08	Cap 0805 220n 10% X7r 16v	R39	038-16180-00	RES 0603 180k 5% 1/10W
C37	018-15100-00	Cap 0603 10n 50v X7r ±10%	R40	038-13180-10	RES 0603 180R 1% 1/10W
C38	018-15100-00	Cap 0603 10n 50v X7r ±10%	R41	038-13180-10	RES 0603 180R 1% 1/10W
C39	018-15100-00	Cap 0603 10n 50v X7r ±10%	R43A	038-13680-00	RES 0603 680R 5% 1/10W
C40	018-15100-00	Cap 0603 10n 50v X7r ±10%	R44	038-13680-00	RES 0603 680R 5% 1/10W
C41	018-15100-00	Cap 0603 10n 50v X7r ±10%	R45	038-13330-00	RES 0603 330R 5% 1/10W
			R47A	038-13120-00	RES 0603 120R 5% 1/10W
D1	001-10084-47	Diode SMD BZX84C4V7 Zen SOT23	R48	038-16120-10	RES 0603 120k 1% 1/10W
D2	001-10099-01	Diode BAV99w Dual Ss	R49	038-16150-10	RES 0603 150k 1% 1/10W
D4	001-10070-01	Diode BAV70W Dual Ss SOT323	R50	038-15120-10	RES 0603 12k 1% 1/10W
D5	001-10084-51	Diode SMD BZX84C5V1 Zen SOT23	R51	038-16120-10	RES 0603 120k 1% 1/10W
D6	001-10084-51	Diode SMD BZX84C5V1 Zen SOT23	R52	038-15470-10	RES 0603 47k 1% 1/10W
D7	001-10084-51	Diode SMD BZX84C5V1 Zen SOT23	R53	038-10000-00	RES 0603 0R
D8	001-10099-01	Diode BAV99w Dual Ss	R54	038-10000-00	RES 0603 0R
D9	001-10084-51	Diode SMD BZX84C5V1 Zen SOT23	R55	038-10000-00	RES 0603 0R
D10	001-10099-01	Diode BAV99w Dual Ss	R56	038-12560-00	RES 0603 56R 5% 1/10W
D11	001-10099-01	Diode BAV99w Dual Ss			
D12	001-10284-51	Diode SMD BZX284B5V1 Zensod110	S1	230-10010-44	Sw SMD Spst 16dil X8
E1	057-10120-03	Ind 0805 120e@100m .2 Emi Supr	SK1	240-00011-67	Skt 15w Drng Ra Slim Dsub 7912
E2	057-10120-03	Ind 0805 120e@100m .2 Emi Supr	SK2	240-10000-11	Conn SMD 18w Skt M/Match
E3	057-10120-03	Ind 0805 120e@100m .2 Emi Supr	T1	054-00010-18	Xfmr Line SMD 600 Ohm P2781
E4	057-10120-03	Ind 0805 120e@100m .2 Emi Supr	T2	054-00010-18	Xfmr Line SMD 600 Ohm P2781
FL1	057-10120-03	Ind 0805 120e@100m .2 Emi Supr			
FL2	057-10120-03	Ind 0805 120e@100m .2 Emi Supr	U1	002-10339-00	IC SMD LM339 4x Cmplt S014
FL3	057-10120-03	Ind 0805 120e@100m .2 Emi Supr	U3	002-10740-40	IC 74AHCT04 SOIC14 Hex Inv
FL4	057-10120-03	Ind 0805 120e@100m .2 Emi Supr	U4	002-10740-80	IC 74AHCT08 SOIC14 4x2IP AND
FL5	057-11220-02	Ind 0603 Blm11a221 Emi Supr	U5	002-10854-10	IC TDA8541T 1w Audio Amp
FL6	057-11220-02	Ind 0603 Blm11a221 Emi Supr	U6	002-10740-80	IC 74AHCT08 SOIC14 4x2IP AND
FL7	057-11220-02	Ind 0603 Blm11a221 Emi Supr	U7	002-10003-58	IC SMD LM358 Dual 0-Amp
FL8	057-11220-02	Ind 0603 Blm11a221 Emi Supr	U8	002-10078-05	IC SMD 78105 5v Reg
FL9	012-14100-00	Cap Cer SMD 1N Array EMI Supr	U9	002-10002-02	IC SMD ADM202E RS232/Esd S016
Q1	000-10084-71	Xstr BC847BW NPN SOT323		220-65202-03	PCB 600 OHM line Interface TMA
Q2	000-10084-71	Xstr BC847BW NPN SOT323		402-00012-0X	MANL f/instr TMAA01-01
Q3	000-10084-71	Xstr BC847BW NPN SOT323			
R1	036-02100-03	RES Pwr 1218 10R 5% 1W			
RV1	042-05100-06	Res Pre TH 10k 6mm Top		600-00009-00 Pkg Kit Opt 15w parts:	
R2	038-15100-10	RES 0603 10k 1% 1/10W		240-00032-00	Plg 15w Drng Hi-D UL-CSA P/Mtg
RV2	042-05100-06	Res Pre TH 10k 6mm Top		240-06010-29	Conn 9w Hood/Cvr Lets
R3	038-14100-10	RES 0603 1k0 1% 1/10W			
RV3	042-05100-06	Res Pre TH 10k 6mm Top		600-00010-00 Pkg Kit Opt Int parts:	
R4	038-15100-10	RES 0603 10k 1% 1/10W		219-00329-00	Loom TMA Int Opt
R5	038-16470-00	RES 0603 470k 5% 1/10W		354-01043-00	Fsnr Scrw Lok 1pr 4-40
R8	038-17100-10	RES 0603 1M 1% 1/10W		362-01108-01	Seal Drng Cvr 9way TMA
R9	036-02100-03	RES Pwr 1218 10R 5% 1W		362-01111-00	Seal Drng 9way TMA
				347-00011-00	Scrw 4-40*3/16 Unc P/P Blk
				349-02062-00	Scrw M3*8 T/T P/T ContiR

## 2.9.2 TMAA01-01 Grid Reference List (PCB IPN 220-65202-03)


Ref.	PCB	Circuit	Ref.	PCB	Circuit	Ref.	PCB	Circuit
C1	B2	2:A2	MT4	G6	2:A7	S1	G3	1:D5
C2	B1	2:A2	MT5	A1	2:A7			1:D11
C3	C5	2:A4	MT6	G1	2:A8			1:F4
C4	F6	1:D5						1:G4
C5	D8	2:G3	Q1	G5	1:E9			1:G9
C7	B6	2:A4	Q2	E2	1:G10			1:J9
C8	D2	2:F6	Q3	C6	1:D4			1:H9
C9	D2	2:G6						1:F9
C10	B6	2:B4	R1	B1	2:B2	SK1	D1	2:B8
C12	E2	1:K3	R2	D6	1:E7			2:F9
C13	F8	2:C3	R3	D2	1:E12			2:C8
C14	D2	2:B6	R4	F8	2:G3			2:G9
C15	C2	2:C6	R5	E6	1:E6	SK1	D1	1:K13
C16	C7	1:B10	R8	E6	1:D5			1:J13
C17	E3	1:K4	R9	C6	2:B3			1:H13
C18	E3	1:J7	R10	B6	2:A4			1:B13
C19	E6	1:A9	R11	C4	1:D2			1:G13
C20	C6	1:A9	R12	E6	1:E5			1:D13
C21	F3	1:K8	R13	E6	1:E5			1:E13
C22	D6	1:A10	R14	C7	1:E4	SK2	B3	2:F1
C24	C1	2:G8	R15A	A7	2:E8			2:C1
C25	E5	1:H2	R15	F8	2:G5			2:B1
C26	F5	1:H3	R16A	A7	2:E8			2:G1
C27	G4	1:G3	R16	E8	2:F5	SK2	B3	1:C1
C28	F4	1:H4	R17	E8	2:F5			1:H1
C29	E5	1:A12	R18	F7	1:E6			1:D1
C30	D6	1:A11	R19	F7	1:D5			1:G1
C31	C1	1:J13	R20	D6	1:D4			1:F1
C32	C1	1:H13	R21	C4	1:D2			1:K1
C33	B1	2:G8	R22	D1	2:B8			
C35	D5	1:J9	R23	D7	1:B8	T1	D4	1:J11
C37	E8	2:E3	R24	C3	1:G2	T2	C4	1:H11
C38	D8	2:E3	R25	F5	1:E9	TP1	B4	1:D2
C39	E8	2:E3	R26	E2	1:G9	TP2	B3	1:F2
C40	E8	2:E4	R27	D7	1:B9	TP3	B4	1:D2
C41	D8	2:E4	R28	E7	1:B9	TP4	B3	1:G2
			R29	E7	1:B10	TP5	D2	1:E13
D1	E1	1:C11	R30	E3	1:F9	TP6	C2	1:G12
D2	D2	1:F12	R31	D2	1:G11	TP7	C2	1:D13
		1:G12	R32	D7	1:B10			
D4	D6	1:C10	R34	F5	1:D9	U1	E7	1:C5
		1:B10	R35	C2	1:D12			1:E6
D5	B3	1:J12	R36	E2	1:E11			1:B9
D6	C2	1:K12	R37	D6	1:B11			1:A11
D7	C3	1:J12	R38	E3	1:K4			1:C4
D8	G5	1:H4	R39	E4	1:K7	U2	E8	2:F3
D9	B2	1:H12	R40	E4	1:K8	U3	F5	1:G6
D10	D2	1:E12	R41	D4	1:J8			1:G7
D11	C2	1:D12	R43A	A7	2:E9			1:F2
D12	B5	2:A3	R43	C8	2:C4			1:B6
			R44	C8	2:B4			1:C10
E1	C2	2:C6	R45	C4	1:H10			1:A9
E2	D2	2:C6	R46	E8	2:F2	U4	E5	1:B6
E3	C1	2:C7	R47A	A7	2:E9			1:A10
E4	D1	2:C7	R47	C8	2:C4			1:E8
			R48	F5	1:H3			1:F3
FL1	D2	2:G6	R49	E5	1:H3	U5	E3	1:J7
FL2	D2	2:F6	R50	F4	1:G3	U6	D5	1:A8
FL3	D1	2:G7	R51	F5	1:H3			1:C10
FL4	D1	2:F7	R52	D2	1:D12			1:B11
FL5	E3	1:K11	R53	C3	1:H11			1:B7
FL6	D3	1:J11	R54	D3	1:J11			1:D3
FL7	C3	1:J11	R55	F8	2:F3	U7	E4	1:H3
FL8	C3	1:H11	R56	E3	1:F10			1:J3
FL9	C1	1:D13	R57	F9	2:F2			1:A12
		1:G13	RV1	E7	1:E5	U8	B5	2:A3
		1:E13	RV2	F2	1:K3	U9	D8	2:E3
			RV3	F4	1:H5	U10	C8	2:C3
MT1	B9	2:A5				W1	C7	1:E4
MT2	G9	2:A6						
MT3	A6	2:A6						

### 2.9.3 Line-Interface Board Layout (top side)




IPN 220-65202-03


## 2.9.4 Line-Interface Board Layout (bottom side)



IPN 220-65202-03

## 2.9.5 Line-Interface Board Circuit Diagram






© TAIT ELECTRONICS A2  
TMAA01-01  
600 OHM INTERFACE

IPN: 226-65202-03 ISSUE: VARIANT NUMBER: H  
FILE DATE: Wed Dec 01 12:06:20 2004  
ENGINEER: Dion Stevenson 226L65202 SHEET NUMBER: 2 OF 2

## 3 TMAA01-02 RS-232 Board



The TMAA01-02 RS-232 board fits inside the radio in the options cavity and is connected to the main PCB by the internal options connector and loom.

The RS-232 signals are then made available on the 9-way D-range connector mounted on the RS-232 board. This connector fits through the external options connector hole provided in the radio chassis.



### **Important**

The radio does not meet the IP54 protection standard once an RS-232 board has been installed unless the external options cover seal is installed.



### **Important**

To comply with EN 301 489-5, all cables connected to the external options connector must be less than three metres (10 feet) in length.

### 3.1 Operation

The TMAA01-02 RS-232 board provides a suitable interface to external devices requiring full RS-232 level compatibility. As well as supporting transmit and receive data lines, the board also supports RTS and CTS hardware flow control lines.

#### 3.1.1 Hardware Flow Control

Although the serial transmit and receive lines are dedicated connections on the internal options connector, the RTS and CTS lines have to be assigned. For hardware flow control, these lines are set up in the programming application. RTS should be assigned to IOP\_GPIO3 and CTS should be assigned to IOP\_GPIO1.

Refer to the online help of the programming application for more information.

## 3.2 Installing the RS-232 Board

### 3.2.1 Parts Required

The following table describes the parts required to install an RS-232 board in a radio. The parts marked with an asterisk (\*) are not shown in Figure 3.1 and are used to connect to the radio's external options connector.

**Table 3.1 RS-232 installation parts required**

Quantity	Internal Part Number	Description	Figure 3.1 Reference
1	362-01111-XX <sup>a</sup>	foam seal	③
1	362-01108-XX <sup>a</sup>	cover seal	⑪
2	347-00011-00	4-40x3/16 screws	⑫
2	354-01043-00	screw-lock fasteners	⑦
4	349-02062-00	M3x8 screws	⑨
★1	240-00034-00	D-range plug	—
★1	240-06010-29	D-range hood	—

a. Contact Technical Support for the exact IPN.

### 3.2.2 Installation Procedure

1. Disassemble the radio in order to gain access to the options cavity.  
For detailed disassembly instructions, refer to the disassembly procedure in the service manual.

Refer to the diagram on the following page and the instructions below.

2. Remove the top cover and lid ① from the radio to access the options cavity.
3. Remove the external options connector bung ②, if it is fitted.
4. On the inside of the radio lid place the foam seal ③ over the external options connector cavity ④.
5. Plug one end of the internal options connector loom into the internal options connector on the RS-232 board.
6. With the top side of the RS-232 board ⑤ facing the radio lid, guide the external options connector ⑥ (the D-range connector on the RS-232 board) into the external options connector cavity.



**Important** The external options connector screw-lock fasteners must be tightened correctly before screwing the RS-232 board onto the mounting posts ⑧.

7. Screw the external options connector to the radio lid using the two screw-lock fasteners ⑦.

Tighten the fasteners to a torque of 0.9N·m (8lbf·in).

8. Screw the RS-232 board to the mounting posts on the radio lid using four M3x8 self-tapping screws ⑨.


Tighten the M3x8 screws to a torque of 1.9N·m (17lbf·in)



**Important** For the RS232 board to be installed correctly in the radio's options cavity, the internal options connector loom ⑩ must be looped in the way shown in [Figure 3.1](#).

9. Plug the unattached end of internal options connector loom ⑩ into the internal options connector on the radio main PCB.
10. Refit the radio lid and top cover to the radio and screw the external options cover seal ⑪ over the external options connector, using the two 4-40x3/16 screws ⑫.

**Figure 3.1 RS-232 board installation**



### 3.3 Interface Specification

The following tables summarize the signals used for the RS-232 board on the internal options connector (SK1 on the RS-232 board) and the external options connector (SK2 on the RS-232 board).



**Note** The TM8000 3DK Hardware Developer's Kit Application Manual (product code MMAA30-01-00-807) contains a detailed electrical specification for the signals available on the radio's internal options connector. This manual is part of the 3DK Resource CD, which can be purchased using product code TMAA30-01.

**Table 3.2 Internal options connector—pins and signals**


	Pin	Connector Signal	Description
<p>top view</p>	1	13V8_SW	switched 13V8 supply from the radio
	2	AUD_TAP_OUT	Programmable tap point out of the receive or transmit audio chain. DC-coupled
	3	AGND	analogue ground
	4	AUX_MIC_AUD	Auxiliary microphone input, with electret microphone biasing provided. Dynamic microphones are not supported.
	5	RX_BEEP_IN	receive sidetone input, AC-coupled
	6	AUD_TAP_IN	Programmable tap point into the receive or transmit audio chain. DC-coupled
	7	RX_AUD	not connected
	8	RSSI	analogue RSSI output
	9-15	IOP_GPIO1 to IOP_GPIO7	programmable function and direction
	16	DGND	digital ground
	17	IOP_RXD	an RS-232 compliant asynchronous serial port - receive data
	18	IOP_TXD	an RS-232 compliant asynchronous serial port - transmit data

**Table 3.3 External options connector—pins and signals**

	Pin	Signal	Direction
<p>front view</p>	2	serial transmit data	output from the radio
	3	serial receive data	input to the radio
	5	data ground	—
	7	RTS using IOP_GPIO3	input to the radio
	8	CTS using IOP_GPIO1	output from the radio




### 3.4.2 RS-232 Board Layout (top side)



IPN 220-01740-01


### 3.4.3 RS-232 Board Layout (bottom side)



IPN 220-01740-01



## 4 TMAA01-05 Options-Extender Board



The TMAA01-05 options-extender board provides external access to most of the signal lines provided by the radio's internal options connector.

The options-extender board fits inside the radio in the options cavity and is connected to the main PCB by the internal options connector and loom.

The internal options connector signals are then made available on the high-density 15-way D-range connector mounted on the options-extender board. This connector fits through the external options connector hole provided in the radio chassis.



### **Important**

The radio does not meet the IP54 protection standard once an options-extender board has been installed unless the external options cover seal is installed.



### **Important**

To comply with EN 301 489-5, all cables connected to the external options connector must be less than three metres (10 feet) in length.

### 4.1 Changing the Options-Extender Links

The options-extender board configuration must be completed before the board is installed in the radio, as the top side of the options-extender board is not accessible once the board is screwed to the radio lid.



### **Important**


This equipment contains devices which are susceptible to damage from static discharges. Refer to [“ESD Precautions” on page 11](#) for more information.

The options-extender board has various link options which allow the user to re-configure the outputs available on the external options connector. The outputs that can be made available by changing linking resistors are:

- the 5V supply line, and
- the RX\_BEEP\_IN line.

In both cases, these lines replace other lines that are available when the linking resistors are in the factory-set configuration. Note that there is no external connection available for the RX\_AUD line.

Figure 4.1 Options-extender board linking resistor locations



### 4.1.1 Power Supply Line

The power supply output available on pin 2 of the external options connector is factory-set to 13.8V. The output on this pin can be changed to 5V if R11 (a 0Ω surface mount resistor) is moved to position R10. [Figure 4.1](#) at the top of the page shows the component locations.



**Important** The maximum current for the 5V supply line is 400mA.

### 4.1.2 RX\_BEEP\_IN Line

If the RX\_BEEP\_IN line is required on the external options connector, it must replace one of the following lines:

- IOP\_RSSI
- AUD\_TAP\_IN
- AUX\_MIC\_AUD
- AUD\_TAP\_OUT.

The following table explains the resistor link changes required and [Figure 4.1](#) at the top of the page shows the component locations.

Table 4.1 RX\_BEEP\_IN resistor changes

RX_BEEP_IN Line Replaces	Remove Resistor	Add Resistor
IOP_RSSI	R2	R3
AUD_TAP_IN	R4	R5
AUX_MIC_AUD	R6	R7
AUD_TAP_OUT	R8	R9

## 4.2 Installing the Options-Extender Board

### 4.2.1 Parts Required

The following table describes the parts required to install an options-extender board in a radio. The parts marked with an asterisk (\*) are not shown in [Figure 4.2](#) and are used to connect to the radio's external options connector.

**Table 4.2 Options-extender installation parts required**

Quantity	Internal Part Number	Description	Figure 4.2 Reference
1	362-01111-XX <sup>a</sup>	foam seal	③
1	362-01108-XX <sup>a</sup>	cover seal	⑪
2	347-00011-00	4-40x3/16 screws	⑫
2	354-01043-00	screw-lock fasteners	⑦
4	349-02062-00	M3x8 screws	⑨
★1	240-00010-80	D-range plug	—
★1	240-06010-29	D-range hood	—

a. Contact Technical Support for the exact IPN.

### 4.2.2 Installation Procedure

1. Disassemble the radio in order to gain access to the options cavity.  
For detailed disassembly instructions, refer to the disassembly procedure in the service manual.

Refer to the diagram on the following page and the instructions below.

2. Remove the top cover and lid ① from the radio to access the options cavity.
3. Remove the external options connector bung ②, if it is fitted.
4. On the inside of the radio lid place the foam seal ③ over the external options connector cavity ④.
5. With the top side of the options-extender board ⑤ facing the radio lid, guide the external options connector ⑥ (the D-range connector on the options-extender board) into the external options connector cavity.
6. Screw the external options connector to the radio lid using the two screw-lock fasteners ⑦.

Tighten the fasteners to a torque of 0.9N·m (8lbf·in).



#### **Important**

The external options connector screw-lock fasteners must be tightened correctly before screwing the options-extender board onto the mounting posts ⑧.

7. Screw the options-extender board to the mounting posts on the radio lid using four M3x8 self-tapping screws ⑨.


Tighten the M3x8 screws to a torque of 1.9N·m (17lbf·in)



**Important** For the options-extender board to be installed correctly in the radio's options cavity, the internal options connector loom ⑩ must be looped in the way shown in [Figure 4.2](#).

8. Plug the unattached end of internal options connector loom ⑩ into the internal options connector on the radio main PCB.
9. Refit the radio lid and top cover to the radio and screw the external options cover seal ⑪ over the external options connector, using the two 4-40x3/16 screws ⑫.

**Figure 4.2 Options-extender board installation**



## 4.3 Interface Specification

The following tables summarize the signals used for the options-extender board on the internal options connector (SK1 on the options-extender board) and the external options connector (SK2 on the options-extender board).




**Note** The TM8000 3DK Hardware Developer's Kit Application Manual (product code MMAA30-01-00-807) contains a detailed electrical specification for the signals available on the radio's internal options connector. This manual is part of the 3DK Resource CD, which can be purchased using product code TMAA30-01.

**Table 4.3 Internal options connector—pins and signals**

	Pin	Connector Signal	Description
 <p>top view</p>	1	13V8_SW	switched 13V8 supply from the radio
	2	AUD_TAP_OUT	Programmable tap point out of the receive or transmit audio chain. DC-coupled
	3	AGND	analogue ground
	4	AUX_MIC_AUD	Auxiliary microphone input, with electret microphone biasing provided. Dynamic microphones are not supported.
	5	RX_BEEP_IN	receive sidetone input, AC-coupled
	6	AUD_TAP_IN	Programmable tap point into the receive or transmit audio chain. DC-coupled
	7	RX_AUD	not connected
	8	RSSI	analogue RSSI output
	9-15	IOP_GPIO1 to IOP_GPIO7	programmable function and direction
	16	DGND	digital ground
	17	IOP_RXD	an RS-232 compliant asynchronous serial port - receive data
	18	IOP_TXD	an RS-232 compliant asynchronous serial port - transmit data

**Table 4.4 External options connector—pins and signals**

	Pin	Signal	Description
	2	13V8_SW <sup>a</sup>	13V8 supply
	6	AUD_TAP_OUT <sup>b</sup>	Programmable tap point out of the Rx or Tx audio chain. DC-coupled
	7	AGND	analogue ground
	11	AUX_MIC_AUD <sup>b</sup>	Auxiliary microphone input, with electret microphone biasing provided. Dynamic microphones are not supported.
	1	AUD_TAP_IN <sup>b</sup>	Programmable tap point into the Rx or Tx audio chain. DC-coupled.
	3	RSSI <sup>b</sup>	analogue RSSI output
	15	IOP_GPIO1 <sup>c</sup>	programmable function and direction
	14	IOP_GPIO2 <sup>c</sup>	programmable function and direction
	13	IOP_GPIO3 <sup>c</sup>	programmable function and direction
	10	IOP_GPIO4 <sup>c</sup>	programmable function and direction
	9	IOP_GPIO5 <sup>c</sup>	programmable function and direction
	5	IOP_GPIO6 <sup>c</sup>	programmable function and direction
	4	IOP_GPIO7 <sup>c</sup>	programmable function and direction
	8	IOP_RXD	an RS-232 compliant asynchronous serial port - receive data
	12	IOP_TXD	an RS-232 compliant asynchronous serial port - transmit data

- a. This can be configured to be 5V. Refer to [“Power Supply Line” on page 44.](#)
- b. This can be re-configured to be RX\_BEEP\_IN. Refer to [“RX\\_BEEP\\_IN Line” on page 44.](#)
- c. 3V3 CMOS output via 1 kΩ series resistance. 5V tolerant input.

## 4.4 PCB Information

### 4.4.1 TMAA01-05 Parts List (PCB IPN 220-65203-00)

Ref.	IPN	Description	Ref.	IPN	Description
C1	018-16100-00	Cap 0603 100n 16v x7r + - 10%	L12	057-10010-20	Ind 0603 Blm11-B102s 0.1a
C2	018-16100-00	Cap 0603 100n 16v x7r + - 10%	L13	057-10010-20	Ind 0603 Blm11-B102s 0.1a
C3	018-16100-00	Cap 0603 100n 16v x7r + - 10%	L14	057-10010-20	Ind 0603 Blm11-B102s 0.1a
C4	018-16100-00	Cap 0603 100n 16v x7r + - 10%	L15	057-10600-05	Ind 0603 Blm11p600s .5a F/Bead
C5	018-16100-00	Cap 0603 100n 16v x7r + - 10%	L16	057-10010-20	Ind 0603 Blm11-B102s 0.1a
C6	018-16100-00	Cap 0603 100n 16v x7r + - 10%	L17	057-10010-20	Ind 0603 Blm11-B102s 0.1a
C7	018-15100-00	Cap 0603 10n 50v X7r ±10%	L18	057-10010-20	Ind 0603 Blm11-B102s 0.1a
C8	014-08100-30	Cap Tant SMD 100u 10v Loesr D			
C9	015-26100-08	Cap Cer 0805 100n 10% X7r 50v	R2	036-10000-00	RES 0805 0R 1/8W
C10	016-08470-01	Cap Elec SMD 47uf 6*4 16v	R4	036-10000-00	RES 0805 0R 1/8W
C11	014-08100-30	Cap Tant SMD 100u 10v Loesr D	R6	036-10000-00	RES 0805 0R 1/8W
C12	018-16100-00	Cap 0603 100n 16v x7r + - 10%	R8	036-10000-00	RES 0805 0R 1/8W
C13	016-08470-01	Cap Elec SMD 47uf 6*4 16v	R11	036-10000-00	RES 0805 0R 1/8W
C14	018-15100-00	Cap 0603 10n 50v X7r ±10%	R12	038-13100-10	RES 0603 100R 1% 1/10W
C15	018-15100-00	Cap 0603 10n 50v X7r ±10%	R13	038-13100-10	RES 0603 100R 1% 1/10W
C16	018-15100-00	Cap 0603 10n 50v X7r ±10%	R14	038-13100-10	RES 0603 100R 1% 1/10W
C17	015-07220-35	Cap Cer 1210 2u2 X5R 35v	R15	038-13100-10	RES 0603 100R 1% 1/10W
C18	015-06470-01	Cap Cer 1206 470n X7r 20% 50v	R16	038-13100-10	RES 0603 100R 1% 1/10W
C19	018-13470-00	Cap 0603 470p 50v X7r±10%	R17	038-13100-10	RES 0603 100R 1% 1/10W
C20	018-13470-00	Cap 0603 470p 50v X7r±10%	R18	038-13100-10	RES 0603 100R 1% 1/10W
C21	018-13470-00	Cap 0603 470p 50v X7r±10%	R19	038-13100-10	RES 0603 100R 1% 1/10W
C22	018-13470-00	Cap 0603 470p 50v X7r±10%			
C23	018-13470-00	Cap 0603 470p 50v X7r±10%	SK1	240-10000-11	Conn SMD 18w Skt M/Match
C24	018-13470-00	Cap 0603 470p 50v X7r±10%	SK2	240-00011-67	Skt 15w Drng Ra Slim Dsub 7912
C25	018-13470-00	Cap 0603 470p 50v X7r±10%			
C26	018-13470-00	Cap 0603 470p 50v X7r±10%		220-65203-00	PCB TM8000 Options Extender
C27	018-13470-00	Cap 0603 470p 50v X7r±10%		402-00008-0X	MANL f/instr TMAA01-05
C28	018-15100-00	Cap 0603 10n 50v X7r ±10%			
C29	015-07220-35	Cap Cer 1210 2u2 X5R 35v			
C30	018-14100-00	Cap 0603 1n 50v X7r ±10%			
C31	018-14100-00	Cap 0603 1n 50v X7r ±10%			
C32	018-14100-00	Cap 0603 1n 50v X7r ±10%			
C33	018-14100-00	Cap 0603 1n 50v X7r ±10%			
C34	018-14100-00	Cap 0603 1n 50v X7r ±10%			
C35	018-14100-00	Cap 0603 1n 50v X7r ±10%			
C36	018-14100-00	Cap 0603 1n 50v X7r ±10%			
D1	001-10014-03	Diode SMD MBRS140T3 Sch			
D2	001-10099-01	Diode BAV99w Dual Ss			
D3	001-10099-01	Diode BAV99w Dual Ss			
D4	001-10099-01	Diode BAV99w Dual Ss			
D5	001-10099-01	Diode BAV99w Dual Ss			
D6	001-10099-01	Diode BAV99w Dual Ss			
D7	001-10099-01	Diode BAV99w Dual Ss			
D8	001-10099-01	Diode BAV99w Dual Ss			
IC1	002-10020-20	IC SMD ADM202 Rs-232 Con S0-16			
IC2	002-10267-40	IC LM2674 S08 Swtch Volt Regul			
L1	057-10100-65	Ind SMD Pwr Cdrh6D38 100UH .65			
L2	057-10010-20	Ind 0603 Blm11-B102s 0.1a			
L3	057-10010-20	Ind 0603 Blm11-B102s 0.1a			
L4	057-10010-20	Ind 0603 Blm11-B102s 0.1a			
L5	057-10010-20	Ind 0603 Blm11-B102s 0.1a			
L6	057-10010-20	Ind 0603 Blm11-B102s 0.1a			
L7	057-10010-20	Ind 0603 Blm11-B102s 0.1a			
L8	057-10010-20	Ind 0603 Blm11-B102s 0.1a			
L9	057-10010-45	Ind SMD Pwr CDRH2D18 10UH .43A			
L10	057-10010-45	Ind SMD Pwr CDRH2D18 10UH .43A			
L11	057-10600-05	Ind 0603 Blm11p600s .5a F/Bead			

#### 600-00009-00 Pkg Kit Opt 15w parts:

240-00032-00	Plg 15w Drng Hi-D UL-CSA P/Mtg
240-06010-29	Conn 9w Hood/Cvr Lets


#### 600-00010-00 Pkg Kit Opt Int parts:

219-00329-00	Loom TMA Int Opt
354-01043-00	Fsnr Scrw Lok 1pr 4-40
362-01108-01	Seal Drng Cvr 9way TMA
362-01111-00	Seal Drng 9way TMA
347-00011-00	Scrw 4-40*3/16 Unc P/P Blk
349-02062-00	Scrw M3*8 T/T P/T ContiR

#### 4.4.2 TMAA01-05 Grid Reference List (PCB IPN 220-65203-00)


Ref.	PCB	Circuit	Ref.	PCB	Circuit	Ref.	PCB	Circuit
C1	D5	1G4	L17	D1	1F7			
C10	F3	1G5	L18	D1	1E2			
C11	E3	1G8	L2	B2	1C2			
C12	E2	1G8	L3	B2	1A2			
C13	F2	1G5	L4	C2	1B3			
C14	D2	1E2	L5	C2	1D2			
C15	D2	1D2	L6	C2	1B3			
C16	D2	1D2	L7	C2	1C3			
C17	E1	1G9	L8	C2	1B2			
C18	B1	1G2	L9	E2	1G9			
C19	B1	1F8						
C2	D4	1F2	R1	B4	1A2			
C20	B1	1C2	R10	D1	1F9			
C21	B1	1A2	R11	D1	1G9			
C22	C1	1B3	R12	C4	1D2			
C23	C1	1D2	R13	C4	1C2			
C24	C1	1B3	R14	C4	1C2			
C25	C1	1C3	R15	C4	1B2			
C26	C1	1B2	R16	C4	1B2			
C27	D1	1F8	R17	C4	1B2			
C28	D1	1E2	R18	C4	1A2			
C29	F1	1G4	R19	C3	1E2			
C3	D4	1G4	R2	B3	1E2			
C30	C4	1D1	R20	B2	1F2			
C31	C4	1C1	R21	D2	1F2			
C32	C4	1C1	R3	C3	1E2			
C33	C4	1B1	R4	B3	1E2			
C34	C4	1B1	R5	C3	1E2			
C35	C4	1B1	R6	B3	1E2			
C36	C4	1A1	R7	C3	1E2			
C4	D4	1G2	R8	B3	1D2			
C5	D4	1G4	R9	C3	1D2			
C6	E4	1G7						
C7	F3	1G7	SK1	B3	1D2			
C8	E3	1G8			1G2			
C9	F3	1G6			1E2			
					1F2			
D1	G3	1G7			1D1			
D2	B2	1A2			1C1			
D3	C2	1D2			1B1			
D4	C2	1C3			1A1			
D5	B2	1C2	SK2	D1	1D9			
D6	C2	1C3 1B3			1C9			
D7	C2	1B3			1A9			
D8	C2	1B2			1B9			
					1E9			
IC1	D4	1F3			1F9			
IC2	F3	1G6						
L1	F4	1G7						
L10	F2	1G5						
L11	E2	1G9						
L12	D2	1E2						
L13	D2	1D2						
L14	D2	1E2						
L15	F1	1G5						
L16	B1	1F7						

### 4.4.3 Options-Extender Board Layout (top side)




IPN 220-65203-00

### 4.4.4 Options-Extender Board Layout (bottom side)



IPN 220-65203-00

# 4.4.5 Options-Extender Board Circuit Diagram



© TAIT ELECTRONICS A2  
 19000  
 OPTIONS EXTENDER BOARD  
 IPK ISSUE: VARIANT NUMBER:  
 220-65203-00 00A  
 FILE DATE: Mon Jan 17 10:28:14 2005  
 ENGINEER: Matt Opie SHEET NUMBER:  
 220-65203 1 of 1

REV/ISS	1	2	3	4	5	6	7	8	9	10
00A	CHANGED IPN FROM 226-00129-03 TO 220-65203-00	APPENDMENTS	DRANN	CHD	D.O.	7	7	7	7	15/03/04
REV/ISS										

# 5 TMAA02-02 DTMF Microphone



The TMAA02-02 DTMF microphone plugs into the microphone socket on the radio control head, and enables users to make calls to a PABX or PSTN.

To make a call, enter the required number using the DTMF keypad and the DTMF microphone generates audible DTMF tones as the microphone keys are pressed. Press the PTT key and speak clearly into the microphone then release the PTT key when you have finished speaking.

The microphone button operates a hookswitch, which is closed when the microphone is connected to the microphone clip and open when the microphone is removed from the microphone clip. The function of the hookswitch is determined by the radio programming.

## 5.1 Installation

Installing the Microphone




**Important**

The DTMF microphone grommet must be installed whenever the microphone is plugged into the microphone socket. When installed, the grommet has two functions:

- to prevent damage to the microphone socket when there is movement of the microphone cord, and
- to ensure that the control head is sealed against water, dust and other environmental hazards.

1. Plug the DTMF microphone cord into the microphone socket on the radio control head.
2. Slide the microphone grommet along the microphone cord and push two adjacent corners of the grommet into the microphone socket cavity.
3. Squeeze the grommet and push the remaining corners into position.
4. Check that the grommet is seated correctly in the cavity.

**Figure 5.1 Correct DTMF microphone grommet seating**



## Installing the Microphone Clip

Install the microphone clip in the most convenient location for the radio user. It must be within easy reach of the user, but in such a position that the microphone PTT key cannot be inadvertently activated or jammed on.

Connect the microphone clip to the negative supply if hookswitch operation is required.

## 5.2 Adjustment

Remove the DTMF microphone back cover and set the DTMF tone level to approximately 60% deviation ( $\pm 3$  kHz for wide bandwidth radios and  $\pm 1.5$  kHz for narrow bandwidth radios).

## 5.3 Radio Programming

The following table shows the settings required for CH\_GPIO1 in the Programmable I/O form of the programming application. This setting means that when a key is pressed on the microphone, the DTMF tones are fed into the radio's speaker at a reduced volume, giving the radio user confidence that the tones are being transmitted. Refer to the online help of the programming application for more information.


Table 5.1 DTMF microphone settings in the Programmable I/O form, Digital tab

Pin	Direction	Label	Action	Active	Debounce	Signal State	Mirrored To
CH_GPIO1	Input	None	Send Mic Audio To Spkr	High	None	None	None


## 5.4 Interface Specification

The following table and diagram summarizes the signals used for the DTMF microphone on the radio's microphone connector and shows the interface between the DTMF microphone and the radio.

Table 5.2 DTMF microphone connector—pins and signals

	Pin	Signal	Colour	Description
	1	—	—	not connected
	2	13V8_SW	red	power supply (switched)
	3	—	yellow	not connected
	4	MIC_PTT	black	PTT and hookswitch
	5	MIC_AUD	white	audio from the microphone
	6	AGND	blue	analogue ground
	7	—	—	not connected
	8	MIC_GPIO1	green	mute out

**Figure 5.2 DTMF microphone to radio interface**




## 5.5 Circuit Description

The microphone has a standard 12-key telephone keypad. When one of the keypad keys is pressed, a DTMF tone specific to that key is generated on the MIC\_AUD line (pin 5). For the duration of the tone, the tone generator activates the PTT, so that the user is not required to press the PTT key to transmit each tone.



# 6 TMAA02-06 Support Kit for Concealed & Dynamic Microphones



The support kit for concealed and dynamic microphones can be used in two main applications:

- to monitor activity around the radio if the radio is placed in emergency mode, and
- to support the use of a dynamic microphone, such as that used in the TMAA10-02 handset.

The concealed and dynamic microphone support board plugs onto the radio's control head PCB and contains circuitry for a pre-amplifier and a microphone switch circuit. The concealed electret microphone is installed inside the speaker grille of the control head.

## 6.1 Installation



### Important


This equipment contains devices which are susceptible to damage from static discharges. Refer to [“ESD Precautions” on page 11](#) for more information.

### Disassembling the Radio Control Head

To install the concealed-microphone capsule and concealed and dynamic microphone support board, the control head must be removed from the radio and disassembled. For detailed disassembly instructions, refer to the disassembly procedure in the service manual.

### Installing the Microphone Capsule and Dynamic Microphone Board


1. Disassemble the control head in order to gain access to the speaker grille. This will mean removing the control head PCB, the space frame, and the speaker.
2. Drill a 1 mm diameter hole in the concealed-microphone cavity ① in the position indicated by the small 'dimple' ②.





**Important** To maintain the IP54 protection class, great care must be taken when installing the microphone capsule and seal ③ into the concealed-microphone cavity.

3. Push the microphone capsule and seal into the concealed-microphone cavity, with the capsule wires ④ towards the speaker grille ⑤.
4. Reassemble the control head. This includes reinstalling the speaker ⑥, the space frame ⑦ and the control head PCB ⑧.




Plug the speaker lead into the speaker connector ⑨.


5. On the control head PCB, solder the positive concealed-microphone wire to the MIC+ pad ⑩ and the negative wire to AGND ⑪.



**Note** The positive wire on the microphone capsule is identified by a red stripe.



6. On the control head PCB, remove R11 ⑫ and solder P2 ⑬ and P3 ⑭ in the positions shown.
7. Plug S2 ⑮ and S3 ⑯ on the concealed and dynamic microphone support board onto P2 and P3 on the control head PCB.
8. Re-install the control head on the radio body.



## 6.2 Radio Programming

When the support kit for concealed and dynamic microphones is installed in a radio, two fields in the UI Preferences form of the programming application may need to be selected.

- Enable Options Board Preamp: select this field if a dynamic microphone is installed. An example of an accessory that uses a dynamic microphone is the TMAA10-02 handset.
- Emergency Mic: select Concealed if a concealed microphone is installed.

Refer to the online help of the programming application for more information.




## 6.4 PCB Information


### 6.4.1 TMAA02-06 Parts List (PCB IPN 220-01712-01)

Ref.	IPN	Description	Ref.	IPN	Description
C1	015-26330-08	Cap Cer 0805 330n 5% 10v X7r			
C2	015-26330-08	Cap Cer 0805 330n 5% 10v X7r			
C3	018-15100-00	Cap 0603 10n 50v X7r +-10%			
C4	015-26330-08	Cap Cer 0805 330n 5% 10v X7r			
C5	018-16100-00	Cap 0603 100n 16vx7r+-10%			
C6	018-16100-00	Cap 0603 100n 16vx7r+-10%			
C7	018-16100-00	Cap 0603 100n 16vx7r+-10%			
C8	018-16100-00	Cap 0603 100n 16vx7r+-10%			
C10	018-16100-00	Cap 0603 100n 16vx7r+-10%			
IC1	002-13740-53	IC 74LV4053 Mux/Demux Tssop16			
IC2	002-13745-95	IC 74LV595 8BIT SHIFTREG TSSOP			
Q1	000-10084-71	Xstr BC847BW NPN SOT323			
Q2	000-10085-71	Xstr SMD BC857BW PNP SOT323			
Q3	000-10084-62	Xstr BC846S Dual SOT363 NPN			
Q4	001-10099-01	Diode BAV99w Dual Ss			
R1	038-14220-00	Res 0603 2k2 1/16w +-5%			
R2	038-14680-00	Res 0603 6k8 1/16w +-5%			
R3	038-14470-00	Res 0603 4k7 1/16w +-5%			
R4	038-15470-10	Res 0603 47k 1/16w+-1%			
R5	038-14100-10	Res 0603 1k0 1/16w +-1%			
R6	038-15330-10	Res 0603 33k 1%			
R13	038-15100-10	Res 0603 10k 1/16w +-1%			
R14	038-14100-10	Res 0603 1k0 1/16w +-1%			
R15	038-14100-10	Res 0603 1k0 1/16w +-1%			
R16	038-15470-10	Res 0603 47k 1/16w+-1%			
R17	038-15150-10	Res 0603 15K 1% WDS			
R18	038-15470-10	Res 0603 47k 1/16w+-1%			
R20	036-10000-00	Res M/F SMD 0805 0e 0.125w			
S2	240-10002-00	Skt SMD 8w 2x4 Lo-Prof 2mm			
S3	240-10001-00	Skt SMD 6w 2x3 Lo-Prof 2mm			
	220-01712-01	Pcb Dynamic/Covert Mic			
P2	240-10004-00	Hdr SMD 8w 2x4 Lo-Prof 2mm			
P3	240-10003-00	Hdr SMD 6w 2x3 Lo-Prof 2mm			
	252-00010-41	Mic Capsule Electret 2.7*6mm			
	369-01031-00	Rbbr Mic Upper A3M2751 T3K			


### 6.4.2 Concealed and Dynamic Microphone Support Board (top side)



### 6.4.3 Concealed and Dynamic Microphone Support Board (bottom side)



## 6.4.4 Concealed and Dynamic Microphone Board Circuit Diagram



© TAIT ELECTRONICS A3  
 TM8115 OPTIONS BOARD  
 CONCEALED/DYNAMIC MIC  
 IPN: 220-01712-01 VARIANT NUMBER: N.A  
 ISSUE: 01  
 FILE DATE: Thu Sep 04 14:26:44 2003  
 ENGINEER: Dav Idr FILE NAME: 220L01712 SHEET NUMBER: 1 OF 1

REV/ISS	AMENDMENTS	CHKD	D.O.	APVD	DATE
01B	UPDATE BOARD ID FIELDS CONCEALED MIC	DRAMM			04/09/03



# 7 TMAA02-07 Concealed Microphone



concealed microphone  
(capsule, rubber seal & wires)

The concealed microphone can be used to monitor activity around the radio if the radio is placed in emergency mode, and is installed beside the speaker grille of the graphical-display control head.

## 7.1 Installation



**Important** This equipment contains devices which are susceptible to damage from static discharges. Refer to “ESD Precautions” on page 11 for more information.

### Removing the Radio Control Head


To install the concealed-microphone capsule, the control head must be removed from the radio.



**Important** During this procedure, take care that the control-head seal is not damaged. Damage to this seal reduces environmental protection.

1. On the underside of the radio, insert a 5 mm (3/16 inch) flat-bladed screwdriver between the control head and the control-head seal, in either position ① or ②.


Insertion points ① and ② are lever points and are indicated on the radio chassis by a dot-dash-dot pattern (•—•).



2. Use the screwdriver to lift the control head off the chassis clip, then repeat in the other position.
3. Unplug the control head loom from the radio body.

### Installing the Microphone Capsule


1. Unscrew the two screws holding the adaptor flange to the control head. The adaptor flange can now be separated from the control head.
2. Drill a 1 mm diameter hole in the concealed-microphone cavity ①, in the position indicated by the small ‘dimple’ ②.






**Important** To maintain the IP54 protection class, great care must be taken when installing the microphone capsule and seal ③ into the concealed-microphone cavity.

3. Push the microphone capsule and seal into the concealed-microphone cavity.
4. On the control head PCB, solder the negative wire to the COV MIC- pad ④ and the positive concealed-microphone wire to the COV MIC+ pad ⑤.



**Note** The positive wire on the microphone capsule is identified by a red stripe.

5. Re-install adaptor flange onto the control head.
6. Plug the control head loom onto the control head connector ①.
7. Insert the bottom edge of the control head onto the two clips in the front of the radio chassis ②, then snap into place.



## 7.2 Radio Programming

When the concealed microphone is installed in a radio for use in emergency situations, a field in the UI Preferences form, Audio tab of the programming application may need to be selected.

- Emergency Mic: select Concealed.

Refer to the online help of the programming application for more information.

# 8 TMAA02-08 Keypad Microphone



The TMAA02-08 keypad microphone plugs into the microphone socket on the graphical-display radio control head, and enables users to make calls to other radios, groups, or to a PABX or PSTN. The types of call that you can make depends on the way your radio has been programmed.

As well as the PTT key, there are twelve alphanumeric keys, two scroll keys, and a left and right selection key on the keypad microphone. The selection keys and scroll keys duplicate the keys on the control head and the 12 alphanumeric keys on the keypad microphone are used to dial call strings and enter text.

The microphone button operates a hookswitch, which is closed when the microphone is connected to the microphone clip, and open when the microphone is removed from the microphone clip. The function of the hookswitch is determined by the way the radio is programmed.

## 8.1 Operation

**Dialling Characters** If an incorrect character has been dialled, use the left selection key on either the microphone keypad or control head to clear it and move back one character.

**Dialling Text Messages** When the keypad microphone is used to enter a text message, the microphone keys have special functions. Use the **#** key to toggle between upper and lower case characters and use the left selection key **◀** to delete a character from the display.

The alphanumeric keys **0** to **9** are used to enter letters, numbers and punctuation. Repeated presses of these keys will give you the characters shown in the table below.

Key	Characters	Key	Characters
<b>1</b>	. , ? ! 1	<b>7</b> PQRS	P Q R S 7
<b>2</b> ABC	A B C 2	<b>8</b> TUV	T U V 8
<b>3</b> DEF	D E F 3	<b>9</b> WXYZ	W X Y Z 9
<b>4</b> GHI	G H I 4	<b>0</b>	space 0
<b>5</b> JKLM	J K L 5	<b>*</b>	*
<b>6</b> MNOP	M N O 6		

## 8.2 Installation

### Installing the Microphone



#### **Important**

The keypad microphone grommet must be installed whenever the microphone is plugged into the microphone socket. When installed, the grommet has two functions:

- to prevent damage to the microphone socket when there is movement of the microphone cord, and
- to ensure that the control head is sealed against water, dust and other environmental hazards.

1. Make sure the radio is turned off, then plug the keypad microphone cord into the microphone socket on the radio control head.




#### **Important**

The radio will only recognize the presence of the keypad microphone when the radio is powered on, so that if the microphone is plugged in after the radio has been powered on, it will not recognize the keypad microphone. Also, if the keypad microphone is plugged in on power up but is later unplugged, then plugged back in, the radio will not recognize it again until the next power cycle.

2. Slide the microphone grommet along the microphone cord and push two adjacent corners of the grommet into the microphone socket cavity.
3. Squeeze the grommet and push the remaining corners into position.
4. Check that the grommet is seated correctly in the cavity.

**Figure 8.1 Correct keypad microphone grommet seating**



### Installing the Microphone Clip

Install the microphone clip in the most convenient location for the radio user. It must be within easy reach of the user, but in such a position that the microphone PTT key cannot be inadvertently activated or jammed on.

## 8.3 Radio Programming

The radio does not need to be programmed to recognize the presence of a keypad microphone, as this is automatically done when the radio is powered on. However, there are a few related fields that should be configured, as required, to enable the keypad microphone to be used effectively.



**Note** You **must** power-cycle the radio after replacing the keypad microphone with a programming lead, in order to read or program the radio.

**Conventional Forms** In conventional mode, there are check boxes labelled “Selcall Call Dialling”, “DTMF Call Dialling” and “Phone Patch Call Dialling”. There is also an option “Conventional Dialling Type” field, where you can program the radio to dial labels or channels from the default display.

Refer to the online help of the programming application for more information about these programming options.

**MPT Trunked Forms** In MPT trunked mode, there may be check boxes labelled “DTMF Dialling”, “PABX Calls” and “PSTN Calls”. These check boxes need to be selected before you can make these types of calls.

Refer to the online help of the programming application for more information about these programming options.

## 8.4 Interface Specification

The following table and diagram summarizes the signals used for the keypad microphone on the radio’s microphone connector and shows the interface between the keypad microphone and the radio.

**Table 8.1 Keypad microphone connector—pins and signals**

	Pin	Signal	Colour	Description
	1	RX audio	—	not connected
	2	13.8V	black	power supply
	3	TXD	green	transmit serial data
	4	PTT	white	PTT and hookswitch
	5	MIC	blue	audio from the microphone
	6	GND	red	ground
	7	RXD	yellow	receive serial data
	8	IO	—	not connected




## 9 TMAA03-02 Security Bracket

The TMAA03-02 security bracket can be used in place of the standard U-bracket in locations where you want to stop opportunistic removal of the radio by a third party, or where you want to have a quick release setup that allows you to swap over radios (e.g. leasing situation). The security bracket also provides electrical isolation to the radio.

The parts of the TMAA03-02 security bracket are illustrated in [Figure 9.1](#).

**Figure 9.1** Parts of the TMAA03-02 security bracket



## 9.1 Installing the Security Bracket and Radio

### 9.2 Installation Planning

Before installing the security bracket, make sure that the site you have chosen for the installation meets the following criteria:

1. The site has enough height for the radio to be easily installed and removed.

The measurements given at the bottom of [Figure 9.1](#) are the heights of the radios and base only. Allow extra space for manipulation.



**Note** You will need more space if you are installing a TM8200 radio.

2. The site has enough depth for the radio.

Check that the front and rear overhang of the radios will fit where you are mounting the security bracket.

3. The site allows for good air circulation, particularly at the rear of the radio.

#### Installation Procedure



**Important** The security bracket must be securely installed. Otherwise there is a risk that the whole assembly of the radio and security bracket may become loose over time, or as a result of serious impact.



**Note** Because some model control heads are taller than others, each security bracket kit comes with two different heights of mounting rail and mounting screws, depending on the radio type you are installing.

Once you have identified a suitable site for the security bracket and radio, installation is as follows:

1. Use the four self-tapping screws and washers to fix the security bracket base in place. The base actually has five screw holes available, but the centre screw hole does not need to be used. The layout and dimensions of the five screw holes is identical to that of the T2000 cradle.
2. Depending on whether you are installing a TM8100 or TM8200 radio, select the correct height mounting rails and screws, and attach a rail to each side of the bottom of the radio body (two screws per rail, minimum torque 20in.lbf [2.26N.m]).
3. To insert the radio, with the mounting rails attached, into the security bracket base, check that the left and right slide locks are open.

4. If the slide locks are closed, open them by inserting the slide lock key into the keyhole. Rotate the key 90° (it will slip into a detent), and pull.

Two slide lock keys are supplied so that you can either use them both at once, or so that you can keep one as a spare.

5. Place the radio over the security bracket base so that the feet of the mounting rails fit securely into the base.
6. Close the slide locks by pressing them into the base. You should hear an audible click as the internal spring lock mechanism engages.



**Warning!!** For continued safe operation, replace and do not re-use Security Bracket once it has been involved in a crash greater than 50km/h.

## 9.3 Removing a Radio from the Security Bracket

Remove the radio from the security bracket as follows:

1. Open the slide locks by inserting the slide lock key into the keyhole. Rotate the key 90° (it will slip into a detent), and pull. The pull will be need to be quite firm to open each slide lock.
2. Remove the radio and its mounting rails by lifting it up and out of the security bracket base.
3. If required, remove the mounting rails from the radio body base by unscrewing them.

## 9.4 Replacing the Radio in the Security Bracket

To replace the radio in a security bracket, first follow the steps in “Removing a Radio from the Security Bracket” on page 73, and then follow from step 2 in “Installing the Security Bracket and Radio” on page 72.

## 9.5 Disassembling the Security Bracket

Disassemble the security bracket as follows:

1. Remove the radio from the security bracket by following the steps in “Removing a Radio from the Security Bracket” on page 73.
2. Unscrew the four self-tapping screws holding the security bracket base in place.

## 9.6 Re-Ordering Extra Parts

The following parts can be re-ordered separately in case of loss, or in situations where, for example, one security bracket is installed where several different radios may be installed at different times.

Part	Part Number	Quantity
Security Crdl Key TM8 (slide lock key)	319-60004-XX <sup>a</sup>	2
Security Crdl Mtg Short TM8 (short mounting rails for TM8100)	319-60002-XX <sup>a</sup>	2
Scrw M4*25 T/T P/T ContiR (for attaching short mounting rails to TM8100 radio)	349-02063-XX <sup>a</sup>	4
Security Crdl Mtg Tall TM8 (tall mounting rails for TM8200)	319-60003-XX <sup>a</sup>	2
Scrw M4*30 T/T P/T ContiR (for attaching tall mounting rails to TM8200 radio)	349-02068-XX <sup>a</sup>	4

a. Contact Technical Support for the exact IPN.

# 10 Installing a Remote Kit

A TMAA03-16 remote kit can be used to install the control head of a graphical-display radio remotely from the radio body. The diagram below shows the parts used for this installation.



**Note** Although the torso interface is similar in appearance to the dual-RJ45 on the telemetry radio, the control head on the telemetry radio cannot be used for remote installation.



**Note** The interfaces in the TMAA03-16 single-head remote kit appear similar to the TMAA03-03, TMAC34-0T or TMAC34-1T. However, the interfaces in the TMAA03-16 are not compatible with TMAA03-03, TMAC34-0T or TMAC34-1T control-head interfaces.

## 10.1 Installation



**Warning!!** Mount the remote U-bracket with the remote control-head assembly and the U-bracket with the radio body securely. These units must not break loose in the event of a collision. Unsecured radio units are dangerous to the vehicle occupants.



**Caution** Observe the installation warnings and safety regulations in the installation procedures of the radio.



**Important** This equipment contains devices which are susceptible to damage from static discharges. Refer to “ESD Precautions” on page 11 for more information.



**Note** Torx T10 and T20 screwdrivers are required for most of the screws in this installation.

The circled numbers in the following sections refer to the items in [Figure 10.1 on page 76](#).

### 10.1.1 Overview


Installing the control head remotely is done in six steps:

1. Remove the control head from the radio body, if necessary.
2. Install the torso interface ① onto the radio body.
3. Mount the remote U-bracket ③ in the required position.
4. Install the control-head interface ② onto the control head and install the remote control-head assembly in the remote U-bracket.
5. Mount the U-bracket in the required position and install the radio body in the U-bracket.
6. Route the remote cable ④ between the remote control-head assembly and the radio body.

### 10.1.2 Parts Required

The following diagram identifies the parts for remote control-head installation and shows how they fit together.

Figure 10.1 Parts for remote control-head installation




### 10.1.3 Removing the Control Head from the Radio Body (if necessary)



**Caution** During this procedure, take care that the control-head seal is not damaged. Damage to this seal reduces environmental protection.

1. On the underside of the radio, insert a 5 mm (3/16 inch) flat-bladed screwdriver between the control head and the control-head seal, in the positions shown.

Insertion points and are lever points and are indicated on the radio chassis by a dot-dash-dot pattern (•—•).




2. Use the screwdriver to lift the control head off the chassis clip, then repeat in the other position.
3. Unplug the control-head loom from the radio body.  
The control head is now separate from the radio body.

### 10.1.4 Installing the Torso Interface

The torso interface must be installed onto the radio body, in place of the existing control head.

1. Screw the solder tag ⑩ onto one of the screw bosses on the radio chassis.
2. Plug the torso-interface loom ⑨ onto the control-head connector.
3. Insert the bottom edge of the torso interface ① onto the two clips in the front of the radio chassis, then snap into place.
4. Remove the bung ⑦ covering the outer RJ45 connector. The remote cable ④ will plug into this connector once the installation is complete.



**Important** The inner RJ45 cavity is not used and has no connector installed so the RJ45-cavity bung must be installed at all times.

This ensures that the torso interface is sealed against water, dust and other environmental hazards.

## 10.1.5 Mounting the Remote U-Bracket

The remote U-bracket with its self-drilling screws, is used to install the remote control-head assembly on the dashboard or on any sufficiently flat surface.



**Caution** When drilling holes in the vehicle, check that drilling at the selected points will not damage existing wiring.




**Important** Check that the remote U-bracket is not distorted when the screws are tightened.

1. Drill any holes required for cables and install suitable grommets or bushings in the holes.
2. If precise positioning is required, predrill  $\varnothing$  3 mm (1/8 inch) pilot holes for the self-drilling screws. Reduce the hole size in metal that is less than 1 mm (1/32 inch) thick.
3. Screw the remote U-bracket in the chosen mounting position using the self-drilling screws provided. Use all four screws provided.

## 10.1.6 Installing the Control-Head Interface

With the control head separated from the radio body, the control-head interface ② must be installed on the rear of the control head.

1. Undo the two Torx T-20 screws on the adaptor flange of the control head, and remove the adaptor flange.
2. Unplug the control-head loom.  
The adaptor flange and control-head loom are not used for the remote control-head installation. Keep the two screws for step (4).
3. Plug the control-head interface loom ⑧ into the connector on the control head.



**Important** When fitting the control-head interface to the control-head, be careful not to damage the space-frame seal.

4. Use the two screws from step (2) to fit the control-head interface to the control head through the two screw holes at the rear of the control-head interface.

### Installing the Remote Control-Head Assembly in the Remote U-Bracket



1. Position the control-head assembly in the remote U-bracket and position it for a good viewing angle.

**Note** Adjusting the contrast on the control-head display may also improve its readability.

2. Screw the remote control-head assembly into position using the two thumb screws provided.

## 10.1.7 Mounting the U-Bracket and Installing the Radio Body

### Mounting the U-Bracket

Install the U-bracket on any sufficiently flat surface, using self-drilling screws and washers.



**Caution** When drilling holes in the vehicle, check that drilling at the selected points will not damage existing wiring, petrol tanks, fuel lines, brake pipes or battery cables.



**Important** When mounting the U-bracket, check whether the mounting surface needs to be reinforced.



**Important** Install the U-bracket using at least four screws.

1. If the U-bracket is being mounted over a curved surface, bend the U-bracket tabs slightly, to match the surface shape.
2. Drill any holes required for cables and install suitable grommets or bushings in the holes.



**Important** Check that the U-bracket is not distorted when the screws are tightened.

3. If precise positioning is required, predrill  $\varnothing$  3mm (1/8 inch) pilot holes for the self-drilling screws. Reduce the hole size in metal that is less than 1 mm (1/32 inch) thick.
4. Screw the U-bracket in the chosen mounting position using the self-drilling screws washers.

### Installing the Radio Body in the U-Bracket

1. Connect the antenna and power cables to the rear of the radio.
2. Position the radio body in the U-bracket so that the holes in the U-bracket line up with the holes in the radio chassis.
3. Screw the radio into position using the four thumb screws.

## 10.1.8 Connecting the Remote Cable



### Caution

When drilling holes in the vehicle, check that drilling at the selected points will not damage existing wiring, petrol tanks, fuel lines, brake pipes or battery cables.

1. Drill any holes required for cables and install suitable grommets or bushings in the holes.
2. Plug one end of the remote cable into the control-head interface.
3. Run the remote cable to the torso interface and plug it into the RJ45 connector without a bung.

### Installing the Remote-Cable Grommets



Install both the remote cable grommets, using the following procedure.


### Important

The remote cable grommets must be installed whenever the remote cable is plugged into the RJ45 sockets. When installed, the grommets have two functions:

- to prevent damage to the RJ45 sockets when there is movement of the remote cable, and
- to ensure that the radio and remote control-head assembly is sealed against water, dust and other environmental hazards.

1. Slide the grommet along the remote cable and push two adjacent corners of the grommet into the RJ45 socket cavity.
2. Squeeze the grommet and push the remaining corners into position.
3. Check that the grommet is seated correctly in the cavity.


Figure 10.2 Correct remote cable grommet seating



## 10.2 Circuit Description

Figure 10.3 shows a block diagram of the remote control-head installation. The control heads contain circuit boards with RS-485 driver components and an audio amplifier or attenuator.

Figure 10.3 Block diagram of remote control-head installation




## 10.3 Servicing the Remote Kit Parts

### 10.3.1 Disassembling the Torso Interface

Disassemble only as much as is necessary to replace the defective parts. Re-assembly is carried out in reverse order of disassembly.

1. Remove the remote cable from the RJ45 connector.
2. Release the clips of the PCB bracket ④ and remove the control-head board ①.
3. Disconnect the torso-interface loom ②.
4. Unscrew the four PT type screws ③ and remove the PCB bracket ④.

Figure 10.4 Parts of the torso interface




### 10.3.2 Disassembling the Control-Head Interface

Disassemble only as much as necessary to replace the defective parts or to swap the Micromatch connector loom. Re-assembly is carried out in reverse order of disassembly.

1. Remove the remote cable from the RJ45 connector.
2. Unscrew the seven PT type screws ① and remove the PCB ②.
3. Remove the control-head interface loom (not illustrated).

**Figure 10.5** Parts of the control-head interface






## Grid Reference List

Ref.	PCB	Circuit	Ref.	PCB	Circuit	Ref.	PCB	Circuit
C101	F3	1D2	R112	G1	1C4			
C102	F2	1D3	R113	M2	1E4			
C103	K1	1D5	R114	M3	1E5			
C104	F4	1E3	R115	M3	1E6			
C105	E4	1D3	R116	M3	1E6			
C106	G1	1C4	R117	M2	1D5			
C107	F1	1C2	R118	M3	1D5			
C108	G1	1C3	R119	M3	1D6			
C109	E4	1C3	R120	M3	1D6			
C110	F4	1B2	R121	M4	1E7			
C111	F4	1B2	R122	L4	1D6			
C112	M3	1E5	R123	K2	1B6			
C113	M3	1D5						
C114	M3	1E6	U101	G3	1D3			
C115	M3	1D6	U102	K1	1C5			
C116	M4	1D6						
C117	M4	1D6						
D101	J2	1C4 1C5						
D102	J1	1C4						
D103	G4	1E2						
D104	J4	1E3						
D105	F4	1D4 1D3						
D106	D4	1B2						
D107	M4	1D7						
E101	F3	1B2						
E102	F4	1B3						
E103	G1	1C3						
E104	G1	1C3						
E105	K3	1D1						
E106	D3	1D1						
E107	E4	1D2						
E108	E4	1C2						
E109	K1	1D5						
F101	F3	1D2						
J100	E4	1C1						
J101	L2	1C7						
MT100	A3	1E1						
MT101	J3	1E1						
Q101	M2	1E5						
R101	K3	1D1						
R102	G4	1E3						
R103	G4	1E3						
R104	D4	1B3						
R105	K1	1B6						
R106	K2	1C5						
R107	K2	1B5						
R108	M2	1B6						
R109	E4	1D3						
R110	G2	1C4						
R111	G1	1C4						



# Circuit Diagram



© TAIT ELECTRONICS A.3  
 TM8200 SINGLE HEAD  
 REMOTE HEAD INTERFACE  
 IPN: 220-02122-02 ISSUE: VARIANT NUMBER: A  
 FILE DATE: Tue Mar 08 13:15:13 2005 SHEET NUMBER: 1 OF 1  
 ENGINEER: S. BELL 220-02122

REV/ISS	AMENDMENTS	3	4	5	6	7
01A	CHANGED FROM 226-02611-01					
		S. BELL	ML	DE	S. BELL	06/12/04
		DRAWN	CHKD	D. O.	APVD	DATE

## 10.4.2 RJ-45 Control Head (PCB IPN 220-02123-01)


### Parts List

Ref.	IPN	Description	Ref.	IPN	Description
C1	015-06470-01	Cap Cer 1206 470n X7r 20% 50v	R6	038-14220-00	Res 0603 2k2 1/10w 5%
C2	018-14470-00	Cap 0603 4n7 50v X7r±10%	R7	038-15100-10	Res 0603 10k 1/10w 1%
C3	015-07220-08	Cap Cer 1206 2u2 16v X7r	R8	038-13560-10	Res 0603 560R 1/10w 1%
C4	018-13470-00	Cap 0603 470p 50v X7r±10%	R9	038-13560-10	Res 0603 560R 1/10w 1%
C5	018-13470-00	Cap 0603 470p 50v X7r±10%	R10	036-02270-10	Res 1206 27.0e 1%
C6	018-14470-00	Cap 0603 4n7 50v X7r±10%	R11	036-02270-10	Res 1206 27.0e 1%
C7	015-23270-05	Cap 0805 270p 1% 200v Grm40	R12	038-13120-00	Res 0603 120R 1/10w 5%
C8	015-23270-05	Cap 0805 270p 1% 200v Grm40	R13	038-16100-10	Res 0603 100k 1/10w 1%
C9	018-15330-00	Cap 0603 33n 50v X7r10%	R14	036-05100-01	Res M/F 1206 10k 5%
C10	015-23270-05	Cap 0805 270p 1% 200v Grm40	U1	002-10078-00	IC SMD MC78M05CDT5v Reg0.5a
C11	015-23270-05	Cap 0805 270p 1% 200v Grm40	U2	002-10014-85	IC ADM1485 RS485 Transc S08
D1	001-10000-99	Diode SMD BAV99 D-Sw SOT23			
DS1	008-00014-74	LED Hp Red Rang PCB Mtg		220-02123-01	PCB Single Rmt Radio I/F
D2	001-10000-99	Diode SMD BAV99 D-Sw SOT23			
D3	001-10000-99	Diode SMD BAV99 D-Sw SOT23			
E1	057-10600-05	Ind 0603 Blm11p600s .5a F/Bead			
E2	057-10600-05	Ind 0603 Blm11p600s .5a F/Bead			
E3	057-10600-05	Ind 0603 Blm11p600s .5a F/Bead			
E4	057-10600-05	Ind 0603 Blm11p600s .5a F/Bead			
E5	057-10020-02	Ind 0603 BIM18pg300 Emi Supr			
J1	240-10000-11	Conn SMD 18w Skt M/Match			
J3	240-00016-00	Conn RJ45 Shld 8P8C LP RA TH			
Q1	000-10561-60	XSTR BCX56-16 AF NPN SOT89			
R1	038-13100-10	Res 0603 100R 1/10w 1%			
R3	038-15100-10	Res 0603 10k 1/10w 1%			
R4	038-13100-10	Res 0603 100R 1/10w 1%			
R5	038-16100-10	Res 0603 100k 1/10w 1%			


### Grid Reference List

Ref.	PCB	Circuit	Ref.	PCB	Circuit	Ref.	PCB	Circuit
C1	F2	1B1	E1	L2	1C5	R13	L2	1D5
C10	M2	1B6	E2	M2	1B6	R14	M2	1E6
C11	M2	1B7	E3	M2	1D6	R2	H2	1D2
C2	H2	1D3	E4	L2	1C6	R3	G2	1D3
C3	J1	1D4	E5	N2	1D6	R4	H2	1D3
C4	J2	1D5				R5	K2	1D3
C5	L2	1D5	J1	H2	1D1	R6	J2	1D4
C6	L2	1C6	J3	N2	1C7	R7	J2	1D4
C7	M2	1C6				R8	K1	1D5
C8	M2	1C6	MT1	R2	1B4	R9	L2	1C5
C9	N2	1C6						
D1	K2	1C4 1D4	Q1	F2	1B1	TP2	M1	1B4
D2	K1	1C5 1D5	R1	F2	1B1	U1	D2	1B2
D3	L2	1D6 1E6	R10	L2	1D5	U2	K1	1C4
DS1	F2	1B1	R11	L2	1C5			
			R12	L2	1C5			

# Board Layout



IPN 220-02123-01





# 11 Installing an Enhanced Remote Kit

The control head of a graphical-display radio can be installed remotely from the radio body. The diagram below shows the parts used for this installation.



TMAA03-03 remote control-head back (includes remote U-bracket)

TMAA04-01 remote cable

TMAC34-0T (TM8200) or TMAC34-1T(TM9100) torso interface



**Note** Although the torso interface is similar in appearance to the dual-RJ45 on the telemetry radio, the control head on the telemetry radio cannot be used for remote installation.

## 11.1 Installation



**Warning!!** Mount the remote U-bracket with the remote control-head assembly and the U-bracket with the radio body securely. These units must not break loose in the event of a collision. Unsecured radio units are dangerous to the vehicle occupants.



**Caution** Observe the installation warnings and safety regulations in the installation procedures of the radio.



**Important** This equipment contains devices which are susceptible to damage from static discharges. Refer to “ESD Precautions” on page 11 for more information.



**Note** Torx T10 and T20 screwdrivers are required for most of the screws in this installation.

The circled numbers in the following sections refer to the items in [Figure 11.1 on page 92](#).

## 11.1.1 Overview


Installing the control head remotely is done in six steps:

1. Remove the control head from the radio body, if necessary.
2. Install the torso interface ① onto the radio body.
3. Mount the remote U-bracket ③ in the required position.
4. Install the control-head interface ② onto the control head and install the remote control-head assembly in the remote U-bracket.
5. Mount the U-bracket in the required position and install the radio body in the U-bracket.
6. Route the remote cable ④ between the remote control-head assembly and the radio body.

## 11.1.2 Parts Required

The following diagram identifies the parts for remote control-head installation and shows how they fit together.

Figure 11.1 Parts for remote control-head installation




### 11.1.3 Removing the Control Head from the Radio Body (if necessary)



**Caution** During this procedure, take care that the control-head seal is not damaged. Damage to this seal reduces environmental protection.

1. On the underside of the radio, insert a 5 mm (3/16 inch) flat-bladed screwdriver between the control head and the control-head seal, in the positions shown.

Insertion points and are lever points and are indicated on the radio chassis by a dot-dash-dot pattern (•—•).




2. Use the screwdriver to lift the control head off the chassis clip, then repeat in the other position.
3. Unplug the control-head loom from the radio body.  
The control head is now separate from the radio body.

### 11.1.4 Installing the Torso Interface

The torso interface must be installed onto the radio body, in place of the control head.

1. Screw the solder tag ⑩ onto one of the screw bosses on the radio chassis.
2. Plug the torso-interface loom ⑨ onto the control-head connector.
3. Insert the bottom edge of the remote control head ① onto the two clips in the front of the radio chassis, then snap into place.
4. Remove one of the bungs ⑦ covering the RJ45 connectors. The remote cable ④ will plug into this connector once the installation is complete.



If the remote cable is not installed in the RJ45 cavity, then the RJ45 bung must be installed. This ensures that the torso interface is sealed against water, dust and other environmental hazards.

### 11.1.5 Mounting the Remote U-Bracket

The remote U-bracket with its self-drilling screws, is used to install the remote control-head assembly on the dashboard or on any sufficiently flat surface.



**Caution** When drilling holes in the vehicle, check that drilling at the selected points will not damage existing wiring.




**Important** Check that the remote U-bracket is not distorted when the screws are tightened.

1. Drill any holes required for cables and install suitable grommets or bushings in the holes.
2. If precise positioning is required, predrill  $\varnothing$  3 mm (1/8 inch) pilot holes for the self-drilling screws. Reduce the hole size in metal that is less than 1 mm (1/32 inch) thick.
3. Screw the remote U-bracket in the chosen mounting position using the self-drilling screws provided. Use all four screws provided.

### 11.1.6 Installing the Control-Head Interface

With the control head separated from the radio body, the control-head interface ② must be installed on the rear of the control head.

1. Undo the two Torx T-20 screws on the adaptor flange of the control head, and remove the adaptor flange.
2. Unplug the control-head loom.  
The adaptor flange and control-head loom are not used for the remote control-head installation. Keep the two screws for step (4).
3. Plug the control-head interface loom ⑧ into the connector on the control head.



**Important** When fitting the control-head interface to the control-head, be careful not to damage the space-frame seal.

4. Use the two screws from step (2) to fit the control-head interface to the control head through the two screw holes at the rear of the control-head interface.

#### Changing the Remote U-Bracket Orientation

The control-head interface is configured for installation with the RJ45 socket facing downwards (U-bracket below control head, as in [Figure 11.1](#)). If the RJ45 socket is required to face upwards (control head hanging from

U-bracket), the control-head interface loom ⑧ must be moved, so that it can reach the control head connector.

To move the control-head interface loom:

1. Undo the seven Torx T-10 screws on the control-head board, and remove the control-head interface board from the control-head interface.
2. Change the control-head interface loom ⑧ to the opposite connector.
3. Reinstall the control-head interface board.

#### Installing the Remote Control-Head Assembly in the Remote U-Bracket

1. Position the control-head assembly in the remote U-bracket and position it for a good viewing angle.

**Note** Adjusting the contrast on the control-head display may also improve its readability.

2. Screw the remote control-head assembly into position using the two thumb screws provided.

### 11.1.7 Mounting the U-Bracket and Installing the Radio Body

#### Mounting the U-Bracket

Install the U-bracket on any sufficiently flat surface, using self-drilling screws and washers.



**Caution** When drilling holes in the vehicle, check that drilling at the selected points will not damage existing wiring, petrol tanks, fuel lines, brake pipes or battery cables.



**Important** When mounting the U-bracket, check whether the mounting surface needs to be reinforced.



**Important** Install the U-bracket using at least four screws.

1. If the U-bracket is being mounted over a curved surface, bend the U-bracket tabs slightly, to match the surface shape.
2. Drill any holes required for cables and install suitable grommets or bushings in the holes.



**Important** Check that the U-bracket is not distorted when the screws are tightened.

3. If precise positioning is required, predrill  $\varnothing$  3 mm (1/8 inch) pilot holes for the self-drilling screws. Reduce the hole size in metal that is less than 1 mm (1/32 inch) thick.

- Screw the U-bracket in the chosen mounting position using the self-drilling screws washers.

#### Installing the Radio Body in the U-Bracket

- Connect the antenna and power cables to the rear of the radio.
- Position the radio body in the U-bracket so that the holes in the U-bracket line up with the holes in the radio chassis.
- Screw the radio into position using the four thumb screws.

### 11.1.8 Connecting the Remote Cable



#### Caution

**When drilling holes in the vehicle, check that drilling at the selected points will not damage existing wiring, petrol tanks, fuel lines, brake pipes or battery cables.**

- Drill any holes required for cables and install suitable grommets or bushings in the holes.
- Plug one end of the remote cable into the control-head interface.
- Run the remote cable to the torso interface and plug it into the RJ45 connector without a bung.

#### Installing the Remote-Cable Grommets



Install both the remote cable grommets, using the following procedure.


#### Important

The remote cable grommets must be installed whenever the remote cable is plugged into the RJ45 sockets. When installed, the grommets have two functions:

- to prevent damage to the RJ45 sockets when there is movement of the remote cable, and
- to ensure that the radio and remote control-head assembly is sealed against water, dust and other environmental hazards.

- Slide the grommet along the remote cable and push two adjacent corners of the grommet into the RJ45 socket cavity.
- Squeeze the grommet and push the remaining corners into position.
- Check that the grommet is seated correctly in the cavity.


**Figure 11.2 Correct remote cable grommet seating**



## 11.2 Circuit Description

Figure 11.3 shows a block diagram of the remote control-head installation. Both control heads contain a circuit board with audio amplifiers and RS-485 driver components.

Figure 11.3 Block diagram of remote control-head installation




## 11.3 Servicing the Remote Control-Head Installation Parts

### 11.3.1 Disassembling the Torso Interface

Disassemble only as much as is necessary to replace the defective parts. Re-assembly is carried out in reverse order of disassembly.

1. Release the clip of the PCB bracket ④ and remove the control-head board ①.
2. Disconnect the torso-interface loom ②.
3. Unscrew the four PT type screws ③ and remove the PCB bracket ④.

Figure 11.4 Parts of the torso interface




### 11.3.2 Disassembling the Control-Head Interface

Disassemble only as much as necessary to replace the defective parts or to swap the Micromatch connector loom. Re-assembly is carried out in reverse order of disassembly.

1. Unscrew the seven PT type screws ① and remove the PCB ②.
2. Remove the control-head interface loom (not illustrated).

Figure 11.5 Parts of the control-head interface



# 11.4 PCB Information

## 11.4.1 TMAA03-03 Control-Head Interface (PCB IPN 220-01721-04)

### Parts List

Ref.	IPN	Description	Ref.	IPN	Description
C1	016-08100-03	Cap Elec SMD 10uF 35V 105/2000	E100	057-10081-06	Ind 1806 Blm41p750s Emi Supr
C100	018-14100-00	Cap 0603 1n 50v X7r ±10%	E101	057-10081-06	Ind 1806 Blm41p750s Emi Supr
C101	018-14100-00	Cap 0603 1n 50v X7r ±10%	E102	057-10600-05	Ind 0603 Blm11p600s .5a F/Bead
C102	015-02470-06	Cap Cer 1210 47p NPO 500v	E103	057-10600-05	Ind 0603 Blm11p600s .5a F/Bead
C103	015-02470-06	Cap Cer 1210 47p NPO 500v	E105	057-10081-06	Ind 1806 Blm41p750s Emi Supr
C110	018-16100-00	Cap 0603 100n 16v x7r + - 10%	E710	057-10600-05	Ind 0603 Blm11p600s .5a F/Bead
C300	015-06470-01	Cap Cer 1206 470n X7r 20% 50v	E711	057-10081-06	Ind 1806 Blm41p750s Emi Supr
C301	016-07470-01	Cap Elec SMD 4u7 6*4 16v 20%	E730	057-10081-06	Ind 1806 Blm41p750s Emi Supr
C310	015-26100-08	Cap Cer 0805 100n 10% X7r 50v	E731	057-10081-06	Ind 1806 Blm41p750s Emi Supr
C312	014-07470-05	Cap Tant SMD 4u7 16v 10% A			
C320	016-08100-03	Cap Elec SMD 10uF 35V 105/2000	J100	240-00016-00	Conn RJ45 Shld 8P8C LP RA TH
C400	018-16100-00	Cap 0603 100n 16v x7r + - 10%	J200	240-10000-11	Conn SMD 18w Skt M/Match
C401	015-07220-08	Cap Cer 1206 2u2 16v X7r	J201	240-10000-11	Conn SMD 18w Skt M/Match
C410	018-16100-00	Cap 0603 100n 16v x7r + - 10%			
C411	018-13100-00	Cap 0603 100p 50v NPO ±5%	L712	057-10100-65	Ind SMD Pwr Cdrh6D38 100UH .65
C420	018-16100-00	Cap 0603 100n 16v x7r + - 10%	L730	057-10470-10	Ind SMD Pwr CDRH104R 47uH 1A
C421	018-13100-00	Cap 0603 100p 50v NPO ±5%	L731	057-10470-10	Ind SMD Pwr CDRH104R 47uH 1A
C422	015-07220-08	Cap Cer 1206 2u2 16v X7r			
C423	015-07220-08	Cap Cer 1206 2u2 16v X7r	Q610	000-10084-71	Xstr BC847BW NPN SOT323
C430	015-07220-08	Cap Cer 1206 2u2 16v X7r	Q720	000-10084-71	Xstr BC847BW NPN SOT323
C500	015-26100-08	Cap Cer 0805 100n 10% X7r 50v	Q721	000-10442-71	Xstr SI4427BDY PCH MOSFET S08
C600	015-26100-08	Cap Cer 0805 100n 10% X7r 50v			
C601	015-26100-08	Cap Cer 0805 100n 10% X7r 50v	R100	038-13100-10	RES 0603 100R 1% 1/10W
C610	015-26100-08	Cap Cer 0805 100n 10% X7r 50v	R110	038-15100-10	RES 0603 10k 1% 1/10W
C611	015-07220-08	Cap Cer 1206 2u2 16v X7r	R200	038-13100-10	RES 0603 100R 1% 1/10W
C612	015-07220-08	Cap Cer 1206 2u2 16v X7r	R201	038-13100-10	RES 0603 100R 1% 1/10W
C700	015-26100-08	Cap Cer 0805 100n 10% X7r 50v	R202	038-13100-10	RES 0603 100R 1% 1/10W
C701	015-07220-35	Cap Cer 1210 2u2 X5R 35v	R210	038-13100-10	RES 0603 100R 1% 1/10W
C702	015-07220-35	Cap Cer 1210 2u2 X5R 35v	R211	038-13100-10	RES 0603 100R 1% 1/10W
C703	015-06470-01	Cap Cer 1206 470n X7r 20% 50v	R212	038-13100-10	RES 0603 100R 1% 1/10W
C704	018-16100-00	Cap 0603 100n 16v x7r + - 10%	R320	036-00000-01	RES 1206 0R 5% 0.25W
C705	018-16100-00	Cap 0603 100n 16v x7r + - 10%	R401	038-15820-10	RES 0603 82k 1% 1/10W
C706	018-13220-00	Cap 0603 220p 50v NPO±5%	R402	038-15820-10	RES 0603 82k 1% 1/10W
C707	015-06470-01	Cap Cer 1206 470n X7r 20% 50v	R410	038-15150-10	RES 0603 15k 1% 1/10W
C708	015-07220-35	Cap Cer 1210 2u2 X5R 35v	R411	038-16150-10	RES 0603 150k 1% 1/10W
C710	015-07220-35	Cap Cer 1210 2u2 X5R 35v	R412	038-13100-10	RES 0603 100R 1% 1/10W
C711	015-07220-35	Cap Cer 1210 2u2 X5R 35v	R420	038-15330-10	RES 0603 33k 1% 1/10W
C712	015-07220-35	Cap Cer 1210 2u2 X5R 35v	R421	038-15220-10	RES 0603 22k 1% 1/10W
C730	015-26220-18	CAP CER 0805 220N 10% X7R 50V	R422	038-12470-00	RES 0603 47R 5% 1/10W
C731	015-26220-18	CAP CER 0805 220N 10% X7R 50V	R430	038-14220-00	RES 0603 2k2 5% 1/10W
C732	018-14100-00	Cap 0603 1n 50v X7r ±10%	R431	038-14220-00	RES 0603 2k2 5% 1/10W
C733	018-14100-00	Cap 0603 1n 50v X7r ±10%	R441	038-14470-10	Res 0603 4k7 1% 100ppm
C734	015-07220-08	Cap Cer 1206 2u2 16v X7r	R442	038-14470-10	Res 0603 4k7 1% 100ppm
C735	015-07220-08	Cap Cer 1206 2u2 16v X7r	R501	038-15100-10	RES 0603 10k 1% 1/10W
			R510	038-13120-00	RES 0603 120R 5% 1/10W
D100	001-10000-99	Diode SMD BAV99 D-Sw SOT23	R511	038-10000-00	RES 0603 0R
D101	001-10000-99	Diode SMD BAV99 D-Sw SOT23	R600	038-15100-10	RES 0603 10k 1% 1/10W
D102	001-10000-99	Diode SMD BAV99 D-Sw SOT23	R601	038-16470-00	RES 0603 470k 5% 1/10W
D103	001-10000-99	Diode SMD BAV99 D-Sw SOT23	R602	038-10000-00	RES 0603 0R
D104	001-10000-99	Diode SMD BAV99 D-Sw SOT23	R603	038-10000-00	RES 0603 0R
D110	001-10084-91	Diode SMD BZX84C9V1 Zen SOT23	R604	038-10000-00	RES 0603 0R
D201	001-10000-99	Diode SMD BAV99 D-Sw SOT23	R605	038-10000-00	RES 0603 0R
D211	001-10000-99	Diode SMD BAV99 D-Sw SOT23	R606	038-15100-10	RES 0603 10k 1% 1/10W
D300	001-10000-99	Diode SMD BAV99 D-Sw SOT23	R607	038-15100-10	RES 0603 10k 1% 1/10W
D720	001-10841-10	Diode SMD BZX84C11v ZEN SOT23	R608	038-15100-10	RES 0603 10k 1% 1/10W
D730	001-10014-03	Diode SMD MBRS140T3 Sch	R609	038-15100-10	RES 0603 10k 1% 1/10W
D731	001-10014-03	Diode SMD MBRS140T3 Sch	R611	038-15100-10	RES 0603 10k 1% 1/10W
			R612	038-14470-10	Res 0603 4k7 1% 100ppm

Ref.	IPN	Description	Ref.	IPN	Description
R701	038-16120-10	RES 0603 120k 1% 1/10W		302-05263-00	Brkt U Thumb Scrw TMA
R710	036-13100-10	RES 0805 100R 1% 1/8W		302-10062-00	Brkt Remote Head TM8200
R720	038-15100-10	RES 0603 10k 1% 1/10W		316-06842-00	Pnl Rear TM8200 MF2
R721	038-14220-00	RES 0603 2k2 5% 1/10W		346-10030-08	Scrw P/T Wn1412 Kc30x08 Zbc
R722	038-14470-10	Res 0603 4k7 1% 100ppm		349-00060-00	Scrw 10G*20 SLFDRL Hex/Poz TMA
R730	038-12470-00	RES 0603 47R 5% 1/10W		353-05007-00	Wshr Rubber M4*19*1.0 S/A
R731	038-12470-00	RES 0603 47R 5% 1/10W		354-01052-00	Fsnr Bush PSM SHK-B-M4 Ins
				402-00015-00	MANL f/instr TMAA03-05
U300	002-10800-00	IC LDO REG LF80C 8V@1A PPAKT/R		410-01183-02	Pkg Box 220x82x65 TMA
U310	002-14931-00	IC L4931CD33 3.3v 250Ma Regso8		410-01197-01	Pkg Ins Lg Ctrl Hd TMA
U400	002-19120-00	IC TS912ID Cmos R2R Opamp			
U500	002-13483-00	IC XCVR RS485 LTD SLEW RATE 3V			
U600	002-15595-00	IC 74AHC595 8bit Shiftreg Tsop			
U610	002-10126-71	IC SMD DS1868 Dgtl Pot Tsop20			
U700	002-13001-00	IC TPA3001 20W Mono PA TSSOP24			
	220-01721-04	PCB MFX Head Remote			
	219-02914-00	LOOM MFX Remote Head			


#### TMAA04-01 Remote Cable Parts

219-02918-00	Cbl Rmt Ctrl Hd Kit, comprising:
219-00025-00	loom 6m shld Bonded+Drain
240-02158-00	Conn Shld RJ45 Shortbody Plg
360-02022-00	Grommet Mic TMA


### Grid Reference List

Ref.	PCB	Circuit	Ref.	PCB	Circuit	Ref.	PCB	Circuit
C1	D1	D7			F4	R321	M4	E8
C100	J3	E3	D102	K4	F4	R401	L3	G10
C101	L4	E3			E4	R402	L3	G10
C102	J4	E3	D103	K4	E5	R410	M3	G8
C103	J4	E3			F5	R411	M3	G7
C110	L4	F4	D104	K5	E5	R412	L4	G7
C300	M5	G2	D110	L5	F3	R420	L3	G6
C301	N5	G3	D201	K5	E8	R421	L3	G6
C310	M2	G4	D211	K5	C9	R422	K3	F7
C311	N2	G4	D300	N5	G3	R430	M2	G9
C312	M2	G5	D301	M5	G2	R431	M2	G9
C320	P4	D8	D720	G1	D2	R440	K3	E5
C400	L3	G10	D730	F3	B7	R441	K3	D5
C401	L3	G10	D731	G3	B7	R442	J3	D5
C410	M3	G8				R501	M4	E7
C411	M3	G8	E100	J5	E2	R510	K4	F6
C420	L3	G5	E101	H5	E2	R511	K4	F6
C421	L3	G6	E102	K4	F3	R600	L2	B1
C422	K3	F7	E103	K4	E4	R601	L2	B2
C423	K3	F7	E105	H5	F2	R602	L1	C1
C430	M2	G9	E710	F2	D7	R603	L2	C1
C500	L4	F6	E711	E2	D7	R604	L2	B1
C600	L2	C3	E730	E4	B8	R605	L2	B3
C601	L2	B2	E731	G4	B8	R606	M2	B3
C610	K1	C5				R607	M2	B3
C611	K1	C4	J100	H4	E1	R608	M2	B3
C612	J2	C5	J200	P3	E10	R609	M2	B4
C700	F2	C6	J201	B4	C10	R610	J2	B5
C701	G3	C7				R611	K1	C4
C702	E3	C7	L712	D2	D8	R612	K1	D4
C703	E2	C6	L730	E4	B9	R701	E3	B6
C704	G2	C6	L731	G4	B9	R710	F2	D6
C705	F2	B6				R720	F1	D1
C706	E3	B6	MT800	D3	B5	R721	F1	D2
C707	E2	B6	MT801	M3	B5	R722	G1	D2
C708	G2	A6				R730	E3	B7
C710	E2	D6	Q610	K1	D4	R731	G3	A7
C711	F2	D7	Q720	F1	D2			
C712	E2	D7	Q721	G2	D3	U300	P5	G3
C720	F1	D2				U310	N2	G4
C721	G1	D2	R100	J3	F2	U400	L3	F6
C730	E3	B8	R110	L4	F3			G7
C731	G3	A8	R200	N4	F8			1G9
C732	F4	B9	R201	R3	E8	U500	L4	F7
C733	G4	B9	R202	R2	E8	U600	L2	B2
C734	F4	B10	R203	J5	E1	U610	K2	B4
C735	F4	B9	R210	C3	D9	U700	F3	B7
			R211	B3	C9			
D100	K3	F4	R212	B4	C9			
		E4	R213	J5	D1			
D101	K4	E4	R320	N4	E8			

# Board Layout



# Circuit Diagram



© TAIT ELECTRONICS A2  
 TM8200  
 PCB MFX HEAD REMOTE  
 JPN: ISSUE: VARIANT NUMBER:  
 220-01721-04 H  
 FILE DATE: Mon Jun 20 11:35:28 2005  
 ENGINEER: David Staten  
 REC:DTZ

REV/ISS	CHG AND RQND SEPARATED	AMENDMENTS	DRAWN	CHKD	D.O.	APUD	DATE
040							16-6-05
REV/ISS							

## 11.4.2 TMAC34-0T Torso Interface (PCB IPN 220-01720-03)


### Parts List

Ref.	IPN	Description	Ref.	IPN	Description
C1	018-16100-00	Cap 0603 100n 16v x7r + - 10%	R12	038-16100-10	RES 0603 100k 1% 1/10W
C2	015-07470-20	CAP Cer 1206 4u7 10% 25V X7R	R13	038-16100-10	RES 0603 100k 1% 1/10W
C3	015-06470-01	Cap Cer 1206 470n X7r 20% 50v	R14	036-13560-10	RES 0805 560R 1% 1/8W
C4	018-13100-00	Cap 0603 100p 50v NPO ±5%	R15	038-15820-10	RES 0603 82k 1% 1/10W
C7	015-27100-08	Cap Cer 0805 X7R 1uF 16V 10%	R16	038-15100-10	RES 0603 10k 1% 1/10W
C9	018-13100-00	Cap 0603 100p 50v NPO ±5%	R17	038-15220-10	RES 0603 22k 1% 1/10W
C10	018-16100-00	Cap 0603 100n 16v x7r + - 10%	R18	038-13220-10	RES 0603 220R 1% 1/10W
C13	018-16100-00	Cap 0603 100n 16v x7r + - 10%	R19	038-14120-10	RES 0603 1k2 1% 1/10W
C15	018-16100-00	Cap 0603 100n 16v x7r + - 10%	R20	038-10000-00	RES 0603 OR
C17	018-16100-00	Cap 0603 100n 16v x7r + - 10%	R21	038-10000-00	RES 0603 OR
C101	018-16100-00	Cap 0603 100n 16v x7r + - 10%	R30	038-13390-10	RES 0603 390R 1% 1/10W
C102	015-07470-20	CAP Cer 1206 4u7 10% 25V X7R	R31	038-13390-10	RES 0603 390R 1% 1/10W
C103	015-07470-20	CAP Cer 1206 4u7 10% 25V X7R	R40	036-00000-01	RES 1206 OR 5% 0.25W
C203	018-13270-00	Cap 0603 270p 50v NPO±5%	R103	038-12100-10	RES 0603 10R 1% 1/10W
C207	018-13270-00	Cap 0603 270p 50v NPO±5%	R104	038-15100-10	RES 0603 10k 1% 1/10W
C209	018-13270-00	Cap 0603 270p 50v NPO±5%	R203	038-13100-10	RES 0603 100R 1% 1/10W
C213	018-13270-00	Cap 0603 270p 50v NPO±5%	R207	038-13100-10	RES 0603 100R 1% 1/10W
DS1	008-00014-73	LED Hp Grn Rang PCB Mtg	R209	038-13100-10	RES 0603 100R 1% 1/10W
J1	240-10000-11	Conn SMD 18w Skt M/Match	R213	038-13100-10	RES 0603 100R 1% 1/10W
J2	240-00016-00	Conn RJ45 Shld 8P8C LP RA TH	R911	036-00000-01	RES 1206 OR 5% 0.25W
J3	240-00016-00	Conn RJ45 Shld 8P8C LP RA TH	R915	036-00000-01	RES 1206 OR 5% 0.25W
R1	038-13120-00	RES 0603 120R 5% 1/10W	R917	038-10000-00	RES 0603 OR
R2	038-10000-00	RES 0603 OR	U1	002-19120-00	IC TS912ID Cmos R2R Opamp
R3	038-15820-10	RES 0603 82k 1% 1/10W	U2	002-12523-17	IC LM317I Reg TO252 0.5a
R4	038-15820-10	RES 0603 82k 1% 1/10W	U3	002-13483-00	IC XCVR RS485 LTD SLEW RATE 3V
R6	038-15220-10	RES 0603 22k 1% 1/10W		219-02950-00	CBL MFX Remote Kit Gnd Lead
R7	038-15100-10	RES 0603 10k 1% 1/10W		220-01720-03	PCB MFX Radio Remote
R8	038-15820-10	RES 0603 82k 1% 1/10W		219-02882-00	Loom Control Head TMA
R9	038-13100-10	RES 0603 100R 1% 1/10W		302-10063-00	Brkt PCB Remote TM8200 Body
R10	038-15100-10	RES 0603 10k 1% 1/10W		302-50002-00	Bung RJ45 MFO
				316-06843-00	Pnl Frt Remote TM8200 MFO


### Grid Reference List

Ref.	PCB	Circuit	Ref.	PCB	Circuit	Ref.	PCB	Circuit
C1	1:J2	1F5	R3	1:J1	1G4	R900	1:F2	1C7
C2	1:K1	1F4	R4	1:J1	1F4	R920	1:D2	1G2
C3	1:D2	1F1	R6	1:J1	1F5	R910	2:J2	1C8
C4	1:J1	1F6	R7	1:G2	1C3	R901	1:E2	1C7
C7	1:J2	1E5	R8	1:J1	1F6	R911	2:L2	1D9
C9	1:K2	1E6	R9	2:L2	1G6	R912	1:H2	1C3
C10	1:N2	1E7	R10	1:K2	1E6	R915	2:M2	1D9
C13	1:N2	1E7	R12	1:N2	1E7	R916	1:M2	1D9
C15	2:L2	1F8	R13	1:N2	1E7	R917	1:N2	1D9
C17	2:L2	1F6	R14	1:F2	1F2	R918	2:M2	1E9
C101	1:J1	1F3	R15	2:L2	1F7			
C102	1:D1	1F2	R16	1:H2	1B3	U1	1:K1	1G6
C103	1:E2	1B5	R18	1:D2	1F2			1E6
C203	1:J2	1B4	R17	2:L2	1F7			1F3
C207	1:H2	1B3	R19	1:E2	1F2	U2	1:D2	1F1
C209	1:H2	1B4	R20	2:L2	1F8	U3	1:F2	1C6
C213	1:H1	1B4	R21	1:N2	1E7			
DS1	1:F2	1F2	R30	1:F2	1B8			
J1	1:H2	1C1	R31	1:E2	1C7			
J2	1:N2	1C10	R40	2:N2	1D9			
J3	1:L2	1E10	R103	1:G2	1B5			
MT1	1:R2	1D10	R104	1:G2	1C5			
R1	2:N2	1C8	R203	1:J2	1C3			
R2	2:P2	1C7	R207	1:J2	1C3			
			R209	1:H2	1C3			
			R213	1:H2	1B3			
			R820	2:L2	1F8			
			R821	1:N2	1E8			


# Board Layout



IPN 220-01720-03



# Circuit Diagram



# 12 TMAA04-04 Crossband Linking Cable



The TMAA04-04 crossband linking cable is used to connect the auxiliary connectors of two radios configured as a crossband repeater. Components in the TMAA04-04 are optimized for voice applications.



**Important** The radio does not meet the IP54 protection standard once the auxiliary connector rubber bung has been removed and a crossband linking cable has been installed. Care must be taken when the radio is being operated in an environment where there is water, dust or other environmental hazards.

## 12.1 Installation

1. Remove the rubber bung that covers the auxiliary connector on each of the radios.
2. Plug each end of the crossband linking cable into the auxiliary connector on each radio.

## 12.2 Radio Programming

After the transmit and receive channels have been programmed for both radios, settings in the following forms must also be configured:

- PTT form (refer to [Table 12.1](#))
- Programmable I/O form — Digital tab (refer to [Table 12.2](#))
- Programmable I/O form — Audio tab (refer to [Table 12.3](#)).

If a repeater transmit tail is required, settings in the following forms must be configured in both radios:

- PTT form (TM8100 radios only) (refer to [Table 12.4](#))
- Basic Settings form—Subaudible Signalling tab (TM8200 radios and optional for TM8100 radios) (refer to [Table 12.5](#) and [Table 12.6](#)).

Some of the settings shown in the tables are default settings and may not need to be changed. In all cases, refer to the online help of the programming application for more information.

### Crossband Settings in the PTT Form

The following table shows the crossband linking settings required in the External PTT (1) tab of the PTT form.

**Table 12.1 Crossband settings in the PTT form, External PTT (1) tab**

Field	Setting	
Advanced EPTT1	PTT Transmission Type	Voice
	Audio Source	Audio Tap In

**Programmable I/O Form—Digital Tab**

The following table shows the crossband linking settings required in the Digital tab of the Programmable I/O form.

**Table 12.2 Crossband settings in the Programmable I/O form, Digital tab**

Pin	Direction	Label	Action	Active	Debounce	Signal State	Mirrored To
AUX_GPI1	Input	PTT_INS	External PTT 1	Low	10	None	None
AUX_GPIO5	Output	BUSY	Busy Status <sup>a</sup>	Low	None	None	None

a. To transmit only when the signalling is valid, set this field to **Signalling Audio Mute Status**.

**Programmable I/O Form—Audio Tab**

The following table shows the crossband linking settings required in the Audio tab of the Programmable I/O form.

**Table 12.3 Crossband settings in the Programmable I/O form, Audio tab**

Pin	Tap In	Tap In Type	Tap In Unmute	Tap Out	Tap Out Type	Tap Out Unmute
Rx	None	A-Bypass In	On PTT	R7	D-Split	Busy Detect <sup>a</sup>
EPTT1	T5	A-Bypass In	On PTT	None	C-Bypass 0	On PTT

a. This can be set to **Busy Detect + Sub** if the mute is to open only when valid subaudible signalling is present with the transmission.

## 12.2.1 Repeater Transmit Tail Settings

### TM8100 Radios

If the transmitter requires a “tail”, then this can be set in the External PTT (1) tab of the PTT form. During the PTT deactivation delay period, any signalling, such as CTCSS or DCS, is still present.

**Table 12.4 Transmit tail settings in the PTT form, External PTT (1) tab**

Field	Setting
Advanced EPTT1	PTT Deactivation Delay up to 1000ms

If a **further** transmitter tail is required, then this can be configured in the Subaudible Signalling tab of the Basic Settings form. During the lead-out delay period, no signalling, such as CTCSS or DCS, is present.

**Table 12.5 Additional Transmit tail in the Basic Settings form, Subaudible Signalling tab**

Field	Setting
CTCSS Settings	Lead-Out Delay any duration, up to 1000ms
DCS Settings	Lead-Out Delay any duration, up to 1000ms

### TM8200 Radios

If the transmitter requires a “tail”, then this can be configured in the Subaudible Signalling tab of the Basic Settings form. During the lead-out delay period, no signalling, such as CTCSS or DCS, is present.

**Table 12.6 Transmit tail in the Basic Settings form, Subaudible Signalling tab**

Field	Setting
CTCSS Settings	Lead-Out Delay any duration, up to 1000ms
DCS Settings	Lead-Out Delay any duration, up to 1000ms


## 12.3 Operational Testing

1. On the receiving radio, inject an on-channel RF signal at a level of -70dBm, modulated to  $\pm 3$ kHz deviation (wide bandwidth channel) or  $\pm 1.5$ kHz (narrow bandwidth channel), at 1kHz AF
2. On the transmitting radio, the resulting deviation should be:
  - $\pm 3$ kHz (with a tolerance of  $\pm 200$ Hz) on a 25kHz wide bandwidth channel.
  - $\pm 1.5$ kHz (with a tolerance of  $\pm 200$ Hz) on a 12.5kHz narrow bandwidth channel.

## 12.4 Interface Specification

The following table and diagram summarizes the signals used for the crossband linking cable on the radios' auxiliary connectors and shows the interface between the cable and the radios.

**Figure 12.1** TMAA04-04 crossband linking cable



**Table 12.7** Auxiliary connectors—pins and signals


	Pin	Signal name	Description
<p>rear view</p>	2	AUX_GPIO5	busy (output)
	7	AUD_TAP_IN	audio tap input
	12	AUX_GPI1	PTT (input)
	13	AUD_TAP_OUT	audio tap output
	15	AGND	analogue ground

## 12.5 PCB Information


### 12.5.1 TMAA04-04 Parts List (PCB IPN 220-02127-01)

<u>Ref.</u>	<u>IPN</u>	<u>Description</u>	<u>Ref.</u>	<u>IPN</u>	<u>Description</u>
C2	018-16100-00	Cap 0603 100n 16v x7r + - 10%			
C10	018-16100-00	Cap 0603 100n 16v x7r + - 10%			
J1	240-00031-00	Plg 15w Drng UL-CSA Pnl Mtg			
R1	038-13560-10	RES 0603 560R 1% 1/10W			
R6	038-13560-10	RES 0603 560R 1% 1/10W			
	205-00110-50	CBL 8wy Oval Std Telecom			
	219-03005-00	CBL TMA X-Band			
	220-02127-01	PCB MFX Programming cable			
	240-00031-00	Plg 15w Drng UL-CSA Pnl Mtg			
	240-06010-18	Conn 15w Hood/Cvr Drng MDJ15			
	402-00030-0X	MANL f/instr TMAA04-04 XB			

## 12.5.2 Crossband Linking Board Layouts



### 12.5.3 Crossband Linking Board Circuit Diagram




© TAIT ELECTRONICS A3  
 TM8000  
 CROSSBAND LINK - RS232  
 IPN: A  
 ISSUE: VARIANT NUMBER: ?  
 220-02127-01  
 FILE NAME: 220-02127  
 ENGINEER: AH  
 FILE DATE: Mon Apr 18 14:32:50 2005  
 SHEET NUMBER: 1 OF 1

Ø1A	NEW IPN - 220-02127-01	STEVE C	JY	CHRIS K	JY	13-4-05
REV/ISS	AMENDMENTS	DRAWN	CHKD	D.O.	APVD	DATE

GP-1 : #220-02127-01B-0520-02127A1504L11PAGE1

# 13 TMAA04-05 Ignition Sense Kit



The TMAA04-05 ignition sense kit provides a mating plug for the radio's auxiliary connector. The four metre length of cable from pin 4 of the plug connects to the vehicle's ignition signal.

Once the kit is installed, the ignition signal is used to power up and power down the radio, so that the radio turns off when the vehicle ignition is off. This avoids any possibility that the radio may flatten the vehicle's battery. When the vehicle ignition is turned on, the radio either turns on, or returns to the state that it was in when the vehicle ignition was turned off.



## **Important**

The radio does not meet the IP54 protection standard once the bung for the auxiliary connector is removed. Therefore, once the TMAA04-05 ignition sense kit is installed, mount the radio in areas where it is not exposed to water, dust or other environmental hazards.

## 13.1 Installation

1. Connect the auxiliary connector plug to the radio's auxiliary connector
2. Connect the ignition sense cable to the 13.8V signal controlled by the vehicle's ignition key.

## 13.2 Radio Programming

Program the AUX GPI3 line to 'Power Sense (Ignition)' and active to 'High'.

Refer to the online help of the programming application for more information.



# 14 TMAA10-01 Desktop Microphone



The TMAA10-01 desktop microphone is an omnidirectional dynamic microphone which can be used in dispatch situations, where the microphone is positioned on a flat surface. The desktop microphone plugs into the microphone socket on the radio control head.

The desktop microphone has an internal pre-amplifier and an adjustable sensitivity control on the underside of the desktop microphone base.

## 14.1 Operation

Hold down the monitor key and check whether the channel is clear.

If the channel is clear, press the PTT key to transmit. Speak clearly into the microphone and release the PTT key when you have finished talking.



**Note** The monitor key can be locked in the 'on' position. To do this, hold the monitor key down and slide the monitor key towards you. The monitor key should now be locked on.

## 14.2 Installation




**Important** The desktop microphone grommet must be installed whenever the desktop microphone is plugged into the microphone socket. When installed, the grommet has two functions:

- to prevent damage to the microphone socket when there is movement of the microphone cord, and
- to ensure that the control head is sealed against water, dust and other environmental hazards.

1. Plug the microphone cord into the microphone socket on the radio control head.
2. Slide the grommet along the cord and push two adjacent corners of the grommet into the microphone socket cavity.

3. Squeeze the grommet and push the remaining corners into position.
4. Check that the grommet is seated correctly in the cavity.

**Figure 14.1 Correct desktop microphone grommet seating**



## 14.3 Adjustment

Adjust the output sensitivity of the desktop microphone using R5. R5 is accessible from the underside of the desktop microphone, as shown.

The microphone sensitivity is set to maximum by rotating R5 counterclockwise.




## 14.4 Interface Specification

The following table and diagram summarizes the signals used for the desktop microphone on the radio's microphone connector and shows the interface between the desktop microphone and the radio.

**Table 14.1 Desktop microphone connector—pins and signals**

	Pin	Signal	Colour	Description
	1	—	—	not connected
	2	—	—	not connected
	3	—	—	not connected
	4	MIC_PTT	yellow	PTT
	5	MIC_AUD	red	audio from the microphone
	6	AGND	bare	analogue ground
	7	—	—	not connected
	8	—	—	not connected

Figure 14.2 Desktop microphone to radio interface



## 14.5 Circuit Description

The desktop microphone uses a dynamic microphone capsule and contains a pre-amplifier (Q1) to boost the microphone level to that required by the radio. Power for the pre-amplifier is provided by the electret microphone bias circuit within the radio. R5 is used to adjust the gain.

PTT and hookswitch signals are combined onto one line and fed to the control head PTT input of the radio.



# 15 TMAA10-02 Handset



The TMAA10-02 handset provides the user with privacy and also improves the audio quality in noisy environments. The handset uses a dynamic microphone capsule, so for TM8100 radios, the TMAA02-06 support kit for concealed and dynamic microphones needs to be installed.

When your radio receives a call and the handset is mounted in its locking cradle, the radio unmutes and you can hear the call from your radio's internal speaker and from any connected remote speaker.

If you remove the handset from its cradle when you receive a call, the radio unmutes and you can hear the call from your radio's internal speaker, from any connected remote speaker and from the handset earpiece.


Using private handset mode, the radio's internal and external speakers are muted and the call can only be heard from the handset earpiece.

## 15.1 Installation

### 15.1.1 Handset Wiring

1. Drill a hole in the chosen mounting surface for the radio to handset cord and pass the cord through the hole.
2. Prepare the radio to handset cord, as follows.
  - Cut the radio to handset cord to the required length.
  - Strip away about 60 mm (2 inches) of the cable outer sheath on the end without a connector.
  - Cut off the exposed orange, red, black and bare wires.
  - Strip about 6 mm (0.2 inches) of the coating off each of the five remaining wires.
3. Secure the radio to handset cord in the handset PCB P-clip ①, as shown in the diagram.
4. Connect the five wires to the handset PCB connector ②.

**Table 15.1 Handset PCB connector wiring**

	Handset PCB Connector	Colour	Reference
	2	white or violet	③
	3	blue	④
	8	brown	⑤
	9	yellow	⑥
	10	green	⑦

### 15.1.2 Handset Installation

1. Press the pushbutton and remove the handset from the locking cradle.
2. Disassemble the locking cradle by removing the four locking cradle screws.
3. Screw the handset mounting plate to the required mounting surface. Note that mounting screws are not provided in this kit.
4. Clamp the top part of the locking cradle onto the mounting plate, and secure it with the four locking cradle screws.

### 15.1.3 Connecting the Handset to the Radio




**Important**

The handset microphone grommet must be installed whenever the handset to radio cord is plugged into the microphone socket. When installed, the grommet has two functions:

- to prevent damage to the microphone socket when there is movement of the microphone cord, and
- to ensure that the control head is sealed against water, dust and other environmental hazards.

1. Plug the radio to microphone cord into the microphone socket on the radio control head.
2. Slide the grommet along the cord and push two adjacent corners of the grommet into the microphone socket cavity.
3. Squeeze the grommet and push the remaining corners into position.
4. Check that the grommet is seated correctly in the cavity.

**Figure 15.1 Correct handset microphone grommet seating**



## 15.2 Radio Programming

### Dynamic Microphone Support

Dynamic microphone support must be enabled in the UI Preferences form of the radio's programming application, so that audio is optimized for dynamic microphones. Refer to the online help of the programming application for more information.

**Table 15.2 Handset settings in the UI Preferences form (TM8100 Programming Application)**

Field	Setting	Selected/Cleared
Audio Setup	Enable Options Board Preamp	selected

**Table 15.3 Handset settings in the UI Preferences form (TM8200, TM9000/TP9000 Programming Application)**

Field	Setting	Selected/Cleared
Audio>Audio Setup	Dynamic Mic Support	selected

### Private Handset Mode

If private handset mode is required, the radio needs to be programmed to mute the audio power amplifier when the handset is out of the cradle. The audio path is then only through the RX AUDIO line to the handset earpiece.

The following table shows the settings required in the Programmable I/O form of the radio's programming application. Refer to the online help of the programming application for more information.



**Note** If private handset mode is programmed, then no audio will be heard from the speakers if the handset is unplugged.


**Table 15.4 Handset settings in the Programmable I/O form, Digital tab**

Pin	Direction	Label	Action	Active	Debounce	Signal State	Mirrored To
CH_GPIO1	Input	None	Force Audio PA Off	High	25	None	None


## 15.3 Interface Specification

The following table and diagram summarizes the signals used for the handset on the radio's microphone connector and shows the interface between the handset and the radio.

**Table 15.5 Handset microphone connector—pins and signals**

	Pin	Signal	Handset PCB Connector	Colour	Description
	1	RX_AUD	8	brown	receive audio to handset
	2	—	—	—	not connected
	3	—	—	—	not connected
	4	PTT	2	white	PTT and hookswitch
	5	MIC	9	yellow	audio from the handset to dynamic-mic support board
	6	GND	10	green	analogue ground
	7	—	—	—	not connected
	8	CH_GPIO1	3	blue	programmable line controlling private mode

**Figure 15.2 Handset to radio interface**



## 16 TMAA10-03 and TMAA10-06 High-Power Remote Speakers



The TMAA10-03 remote speaker (for the 25 W radio) and the TMAA10-06 remote speaker (for the 40 W/50 W radio) are installed in parallel with the radio's existing internal speaker. The remote speaker can then be installed at some distance from the radio, or it can be used to increase the volume of the audio from the radio's existing internal speaker.

The remote speaker cable is terminated with two receptacles. These receptacles are different between the TMAA10-03 and the TMAA10-06 remote speakers.

Two spare receptacles are included with the remote speaker, along with four mounting screws and washers.

### 16.1 Installation

#### Remote Speaker Mounting

1. Choose a mounting position for the remote speaker where it will not interfere with the operation of any of the vehicle controls.
2. Remove the remote speaker from the mounting bracket and use the screws and washers provided to fix the mounting bracket securely in the chosen location.



**Important** Check before drilling that the drill will not damage any components or wiring behind the mounting location.

- If mounting the bracket onto a metal surface, drill two 3.5 mm (0.14 inch) holes in the appropriate locations and secure the bracket with the supplied self tapping screws.
  - If mounting the bracket to any other material, such as plastic, drill two 4.5 mm (0.18 inch) holes and attach the bracket with screws and captive nuts, or similar.
3. Attach the speaker to the mounting bracket using the thumbscrews.
  4. Run the free end of the speaker cable to the radio power cable and install the two receptacles in the power connector, as described in the [“Power Connector Wiring”](#) procedure.



**Important** Check that the speaker cable is protected from engine heat, sharp edges and from being pinched or crushed.


## Power Connector Wiring

Insert the remote speaker receptacles into the power connector socket, as shown in the diagrams below.




**Note** The positive remote speaker wire has a white stripe.  
With the TMAA10-03 remote speaker (25 W radio), insert the positive remote speaker wire into the position nearest to the red wire.  
With the TMAA10-06 remote speaker (40 W/50 W radio), insert the positive remote speaker wire into the upper position (marked “3”).

**Figure 16.1** Power connector wiring of the TMAA10-03 remote speaker



**Figure 16.2** Power connector wiring of the TMAA10-06 remote speaker



# 17 TMAA10-04 Remote PTT Kit and TMAA10-05 Hands-Free Kit



The TMAA10-04 remote PTT kit and the TMAA10-05 hands-free kit plug into the radio's auxiliary connector. Both kits use the remote electret microphone to replace communication through the usual rugged microphone. The rugged microphone can still provide hookswitch operation, if this is required.

The TMAA10-04 kit uses a conveniently mounted remote PTT key for PTT operation. When the remote PTT is activated, the remote microphone is used for communication.

There are three mounting options for the remote microphone and an extension lead is provided for the remote PTT in the TMAA10-04 kit.



### Important

These kits do not meet the IP54 protection standard. Care must be taken when a radio with a TMAA10-04 or TMAA10-05 kit installed is being operated in an environment where there is water, dust or other environmental hazards.

## 17.1 VOX Operation (TMAA10-05 Hands-Free Kit)



Your radio may be able to detect the sound of your voice, so that you can make calls without using the PTT key. Voice-operated transmit (VOX) is turned on and off either by using a function key programmed for VOX or by using the radio's Main menu.

### Changing to VOX Using a Function Key

The function key programmed for VOX toggles VOX between on and off. When VOX is turned on, it remains on until the function key is pressed again.

### Changing to VOX by using the Main Menu

1. Select Menu > Radio Settings > Function Settings > VOX.
2. In the VOX menu, choose **On**.



3. Press **Select**.


While VOX is on, the VOX indication may be programmed to appear below the channel information on your display.




### Changing the Sensitivity of VOX

You may need to change the threshold at which the radio detects your voice and makes a call. To do this, you use the VOX Sensitivity menu.

1. Select Menu>Radio Settings>Function Settings>VOX Sensitivity.



2. In the VOX Sensitivity menu, use the scroll keys  or  to adjust the VOX sensitivity to the desired level.



3. Press **Done** to save this setting.

## 17.2 Installation



### Important

Care should be taken to avoid routing any cables near vehicle pedal controls, steering column and other moving parts.

### Installing the Remote Microphone

1. Choose one of the three mounting options provided for the remote microphone and determine its most appropriate location.  
The mounting position of the microphone should be no more than 50 cm (20 inches) from the user's mouth.
2. Route the remote microphone cable so as not to distract the driver.
3. Mount the remote microphone in the chosen location and check that the microphone and cable are clear of all the usual movements performed by the user.

### Installing the Remote PTT (TMAA10-04)



### Important

The remote PTT must be operable from a normal driving position.

1. Secure the remote PTT in position using the velcro strap and plug the remote PTT cord into the remote PTT extension lead.  
A common position for the remote PTT is on the gear lever of the vehicle.
2. Check that the cord and lead do not interfere with the safe operation of the vehicle.

## 17.3 Radio Programming for the TMAA10-04 Remote PTT Kit

### Remote PTT Settings in the PTT Form

The following table shows the settings required in the PTT form of the programming application. Some of these settings are default settings and may not need to be changed. Refer to the online help of the programming application for more information.



**Note** If hookswitch operation is programmed for the rugged microphone and the Inhibit PTT Transmission When Mic On Hook field is selected in the PTT tab of the PTT form, then the hands-free remote PTT cannot transmit when the rugged microphone hookswitch is closed (the microphone is on the microphone clip).

**Table 17.1 Remote PTT settings in the PTT form, External PTT (1) tab**

Field	Setting	
Advanced EPTT1	PTT Transmission Type	Voice
	Audio Source	AUX MIC

### Remote PTT Settings in the Programmable I/O Form

The following table shows the settings required in the Programmable I/O form of the programming application. Some of these settings are default settings and may not need to be changed. Refer to the online help of the programming application for more information.



**Note** The Programmable I/O form setting for AUX\_GPIO4 must have the default programming settings and the AUX\_GPIO4 pullup resistor on the radio main PCB must be set for the factory default of 3.3V (R769 fitted).

**Table 17.2 Remote PTT settings in the Programmable I/O form, Digital tab**

Pin	Direction	Label	Action	Active	Debounce	Signal State	Mirrored To
AUX_GPI1	Input	None	External PTT 1	Low	25	None	None
AUX_GPIO4	None	None	No Action	None	None	None	None

## 17.4 Radio Programming for the TMAA10-05 Hands-Free Kit

### VOX Settings in the PTT Form

The following table shows the settings required in the PTT form of the programming application. For detailed instructions on how to configure a radio for VOX operation, refer to the section “Configuring VOX” in the online help of the programming application.

**Table 17.3 VOX settings in the PTT form, External PTT (2) or VOX tab**

Field		Setting
EPTT2 or VOX Inhibit	Inhibit PTT When Emergency Active	select <sup>a</sup>
	Inhibit PTT Transmission When Mic on Hook	clear <sup>a</sup>
	Indicate PTT Inhibit to User	clear <sup>a</sup>
Advanced EPTT2 or VOX	PTT Transmission Type	Voice
	Audio Source	AUX MIC
	PTT Priority	Highest <sup>a</sup>

a. These are recommended settings only.

**VOX Settings in the Key Settings Form**

In the Key Settings form of the programming application, one of the function keys on the control head can be programmed to activate VOX.

**Table 17.4 VOX settings in the Key Settings form**


Field		Setting
Function Key Actions	Key 1 <sup>a</sup>	VOX Activation

a. Select the required function key.


## 17.5 Interface Specification

The following table and diagram summarizes the signals used for the remote PTT and hands-free kits on the radio's auxiliary connector and shows the interface between the kits and the radio.

**Table 17.5 Auxiliary connector—pins and signals**

	Pin	Signal name	Description
 <p>rear view</p>	8	+13V8_SW	power to hands-free microphone pre-amplifier
	10	AUX_GPIO4	reference voltage to pre-amplifier regulator
	12	AUX_GPI1	PTT signal from hands-free kit
	14	AUX_MIC_AUD	microphone audio to the radio
	15	AGND	analogue ground

**Figure 17.1 TMAA10-04/TMAA10-05 to radio interface**



## 17.6 Circuit Description

The remote microphone signal is amplified by a pre-amplifier in the auxiliary connector plug. The power supply to this amplifier is provided by the +13.8V supply on the auxiliary connector. This supply is filtered and regulated down to approximately 3.3V. The reference voltage for the regulator is provided by AUX\_GPIO4 line.

The remote microphone signal is fed via AUX\_MIC\_AUD and an input selector to the radio's internal microphone amplifier. The microphone input selected depends on the PTT source used to make the call. If the remote PTT is used, then AUX\_MIC\_AUD is selected. If the control head microphone PTT is used, then CH\_MIC\_AUD is selected. Test points for all other auxiliary connections are provided on the auxiliary connector plug PCB to facilitate the connection of other devices or signals e.g ignition switch signal.

## 17.7 PCB Information


### 17.7.1 TMAA10-04/TMAA10-05 Parts List (PCB IPN 220-01711-01)

Ref.	IPN	Description	Ref.	IPN	Description
C2	015-26330-08	Cap Cer 0805 330n 5% 10v X7r			
C3	018-15100-00	Cap 0603 10n 50v X7r +-10%			
C4	015-26330-08	Cap Cer 0805 330n 5% 10v X7r			
C6	015-26100-08	Cap Cer 0805 100n 10% X7r 50v			
C7	015-26100-08	Cap Cer 0805 100n 10% X7r 50v			
Q1	000-10084-71	Xstr BC847BW NPN SOT323			
Q2	000-10085-71	Xstr SMD BC857BW PNP SOT323			
Q3	000-10084-71	Xstr BC847BW NPN SOT323			
Q4	000-10084-71	Xstr BC847BW NPN SOT323			
R1	038-14220-00	Res 0603 2k2 1/16w +-5%			
R3	038-14390-10	Res 0603 3k9 1%			
R4	038-15470-10	Res 0603 47k 1/16w+-1%			
R6	038-15330-10	Res 0603 33k 1%			
R13	038-15100-10	Res 0603 10k 1/16w +-1%			
R16	038-15470-10	Res 0603 47k 1/16w+-1%			
R17	038-15150-00	Res 0603 15k 1/16w +-5%			
R18	038-15100-10	Res 0603 10k 1/16w +-1%			
R19	038-15100-10	Res 0603 10k 1/16w +-1%			
	219-00305-00	cable			
	220-01711-01	Pcb HFree			
	240-06010-18	Conn 15w Hood/Cvr Drng MDJ15			
	252-00010-72	Mic Electret Unidir 2.5mm Plg			
	402-00006-01	F/Inst TMAA10-04/TMAA10-05 Eng			


#### TMAA10-04 Remote PTT only

236-00001-00 Sw Ptt W/Cbl & Strap

### 17.7.2 Pre-Amplifier Board Layout



### 17.7.3 Pre-Amplifier Board Circuit Diagram



© TAIT ELECTRONICS A3  
 TM8000  
 HANDSFREE PRE-AMP  
 IPN: 220-01711-01 ISSUE: 01A VARIANT NUMBER: N.A  
 FILE DATE: Wed Aug 13 11:15:15 2003  
 ENGINEER: Lindsay L FILE NAME: 220-01711 SHEET NUMBER: 1 OF 1


REV/ISS	AMENDMENTS	DRN	CHKD	D.O.	APUD	DATE
01A	TM8000 AUXILIARY BOARD	RPS				11/08/03
		DRN				

# 18 TOPA-SV-024 Test Unit

The TOPA-SV-024 test unit is used to test and maintain Tait Orca portables (TOP) and TM8000 radios by providing an interface between the radio, a test PC, and an RF communications test set.

The diagram below shows the front panel of the test unit.

Figure 18.1 TOPA-SV-024 test unit




## 18.1 Test Equipment Setup

The diagram on the following page shows how the test unit is connected to the radio, the test PC, and the RF communications test set.



**Note** The test unit can also be connected to a T2000 radio using the T2000-11 cable. Use with T2000 radios is not described in this document.

**Figure 18.2 Test setup**



## 18.2 Operation

This section explains the function of the TOPA-SV-024 test unit controls. The procedure for using the test unit is described in the section of the service manual covering test equipment.

### 18.2.1 TOP / TM8000 switch

This 2-way toggle switch is used to switch attenuation resistors (R4, R5, R6) in and out of the line from the radio's positive speaker output to the positive receive audio/SINAD output of the test unit (before the isolating transformer).

- When set to **TOP**, the attenuation resistors are switched out.
- When set to **TM8000**, the attenuation resistors are switched in (attenuation 10:1).



**Important** Selecting the wrong switch position can result in incorrect SINAD readings.

### 18.2.2 TOP Mod Audio / Off / Mic Audio switch

This 3-way toggle switch is used to switch between **Mod Audio** (Tait Orca portables only), **Mic Audio**, and **Off** (no audio signal).

- With the Tait Orca portables, this switch can be used for setting up dual point modulation by applying modulation to different parts of the radio.
- For normal transmit deviation tests (Tait Orca portables and TM8000), this switch is set to **Mic Audio**.

### 18.2.3 Hook On / Hook Off switch



**Important** When using the test unit with Tait Orca portables, the **Hook On / Hook Off** toggle switch **must** be set to **Hook Off**. Tait Orca portables do not have a hookswitch, and if the switch is set to **Hook On**, the Tait Orca portable F1 function is activated.

This 2-way toggle switch is used to simulate the microphone hookswitch opening ("hook off") and closing ("hook on"). This is done by switching a 12k $\Omega$  resistor (R3) in or out of the MIC\_PTT line.

- When set to **Hook Off**, the 12k $\Omega$  resistor (R3) is switched out of the MIC\_PTT line. This simulates the microphone being removed from the microphone clip.
- When set to **Hook On**, a 12k $\Omega$  resistor (R3) is switched into the MIC\_PTT line. This simulates the microphone being placed on the microphone clip.

## 18.2.4 Rx / Tx/PTT switch

This 2-way toggle switch is used to switch between receive and transmit mode.

- When set to **Rx**, the PTT line is switched to high impedance.
- When set to **Tx/PTT**, the PTT line is pulled to ground.

## 18.2.5 Speaker / Radio / Load switch

This 3-way toggle switch is used during receive audio tests to switch the audio to the test unit speaker (**Speaker**), to the radio's internal speaker (**Radio**) or to a dummy load consisting of R1 and R2 (**Load**).



**Note** This switch does not disconnect the radio's internal speaker on M8100 radios with a user interface. If the switch is set to **Speaker** or **Load**, this simulates an external speaker being connected in parallel to the radio's internal speaker. TM8000 radios without a user interface do not have an internal speaker.

With all settings, a low level audio signal is available for testing through the SINAD port.

### Tait Orca portables

- When set to **Speaker**, only the speaker of the test unit is active.
- When set to **Radio**, only the speaker of the Tait Orca portable is active.
- When set to **Load**, no speaker is active. The audio signal is terminated in the test unit dummy load.

### TM8000 radios with user interface


- When set to **Speaker**, the speakers of the test unit and the TM8000 are both active. The speaker of the TM8000 cannot be disconnected.
- When set to **Radio**, only the speaker of the TM8000 is active.
- When set to **Load**, the TM8000 speaker remains active.

## 18.3 PCB Information


### 18.3.1 Parts List (PCB IPN 220-01418-02A Rev. 4)

Ref.	IPN	Description	Ref.	IPN	Description
BNC1	240-02100-11	Skt Coax BNC 3.5mm Pnl N/Tag	SW1	230-00010-42	Sw Tgl On Off On Dpdt Ms500hb
BNC2	240-02100-11	Skt Coax BNC 3.5mm Pnl N/Tag	SW2	230-00010-57	Sw Tgl Dpdt On-On Pnl Mtg
C1	011-54100-01	Cap Cer Al 1n 10% T/C B 50v	SW3	230-00010-03	Sw Tgl Spst Mini Pnl Mtg
C2	011-54100-01	Cap Cer Al 1n 10% T/C B 50v	SW4	230-00010-16	Sw Tgr Spst 3-Pos Pnl Mtg
C3	020-59100-06	Cap Elec Rdl 100m 16v 6.3x11	SW5	230-00010-03	Sw Tgl Spst Mini Pnl Mtg
C4	011-54100-01	Cap Cer Al 1n 10% T/C B 50v	TRAN	054-00010-17	Xfmr Line 600 Ohm 1:1
PL1	240-00010-55	Plg 15w Drng W-Wrap Pnl Mtg	Not part of the PCB:		
PL2	240-04021-60	Skt 6w Modr Ph Vrt T-Ent	SPKR	032-31820-01	Res M/F Pwr 17x5 8e2 5% 2.5w
R1	032-31820-01	Res M/F Pwr 17x5 8e2 5% 2.5w		250-00010-19	Spkwr C/W Rubber Sealing Ring
R2	032-31820-01	Res M/F Pwr 17x5 8e2 5% 2.5w			
R3	030-55120-20	Res Flm 4x1.6 12k 5% 0.4w			
R4	030-53560-20	Res Flm 4x1.6 560e 5% 0.4w			
R5	030-54270-20	Res Flm 4x1.6 2k7 5% 0.4w			
R6	030-52560-20	Res Flm 4x1.6 56e 5% 0.4w			
R7	030-55100-20	Res Flm 4x1.6 10k 5% 0.4w			


### 18.3.2 PCB Layout



IPN 220-01418-02



# 18.3.3 Circuit Diagram



© TAIT ELECTRONICS A2  
 TM8000 and TOP  
 CALIBRATION BOARD  
 ISSUE: VARIANT NUMBER:  
 220-01418-02 A  
 FILE DATE: Mon Feb 17 11:40:04 2003  
 ENGINEER: J1mmly SHEET NUMBER:  
 220\_01418 1 OF 1

The component values in the schematic diagram are indicative only. Refer to the parts list for actual values used.

Q2A	REV/ISS	MIGRATED AND REDESIGNED	AMENDMENTS	BRD	DRW	CHKD	D. O.	APVD	DATE
				X	X	X		X	17/02/03

# Tait General Software Licence Agreement

---

This legal document is an Agreement between you (the “Licensee”) and Tait Electronics Limited (“Tait”). By using any of the Software or Firmware items prior-installed in the related Tait product, included on CD or downloaded from the Tait website, (hereinafter referred to as “the Software or Firmware”) you agree to be bound by the terms of this Agreement. If you do not agree to the terms of this Agreement, do not install and use any of the Software or Firmware. If you install and use any of the Software or Firmware that will be deemed to be acceptance of the terms of this licence agreement.

The terms of this Agreement shall apply subject only to any express written terms of agreement to the contrary between Tait and the Licensee.

## Licence

TAIT GRANTS TO YOU AS LICENSEE THE NON-EXCLUSIVE RIGHT TO USE THE SOFTWARE OR FIRMWARE ON A SINGLE MACHINE PROVIDED YOU MAY ONLY:

1. COPY THE SOFTWARE OR FIRMWARE INTO ANY MACHINE READABLE OR PRINTED FORM FOR BACKUP PURPOSES IN SUPPORT OF YOUR USE OF THE PROGRAM ON THE SINGLE MACHINE (CERTAIN PROGRAMS, HOWEVER, MAY INCLUDE MECHANISMS TO LIMIT OR INHIBIT COPYING, THEY ARE MARKED “COPY PROTECTED”), PROVIDED THE COPYRIGHT NOTICE MUST BE REPRODUCED AND INCLUDED ON ANY SUCH COPY OF THE SOFTWARE OR FIRMWARE; AND / OR
2. MERGE IT INTO ANOTHER PROGRAM FOR YOUR USE ON THE SINGLE MACHINE (ANY PORTION OF ANY SOFTWARE OR FIRMWARE MERGED INTO ANOTHER PROGRAM WILL CONTINUE TO BE SUBJECT TO THE TERMS AND CONDITIONS OF THIS AGREEMENT).

THE LICENSEE MAY NOT DUPLICATE, MODIFY, REVERSE COMPILE OR REVERSE ASSEMBLE ANY SOFTWARE OR FIRMWARE IN WHOLE OR PART.

## Important Notice

THE SOFTWARE OR FIRMWARE MAY CONTAIN OPEN SOURCE SOFTWARE COMPONENTS (“OPEN SOURCE COMPONENTS”). OPEN SOURCE COMPONENTS ARE EXCLUDED FROM THE TERMS OF THIS AGREEMENT EXCEPT AS EXPRESSLY STATED IN THIS AGREEMENT AND ARE COVERED BY THE TERMS OF THEIR RESPECTIVE LICENCES WHICH MAY EXCLUDE OR LIMIT ANY WARRANTY FROM OR LIABILITY OF THE DEVELOPERS AND/OR COPYRIGHT HOLDERS OF THE OPEN SOURCE COMPONENT FOR THE PERFORMANCE OF THOSE OPEN SOURCE COMPONENTS. YOU AGREE TO BE BOUND BY THE TERMS AND CONDITIONS OF EACH SUCH LICENCE. FOR MORE INFORMATION SEE: <http://support.taitworld.com/go/opensource>

## Title to Software

THIS AGREEMENT DOES NOT CONSTITUTE A CONTRACT OF SALE IN RELATION TO THE SOFTWARE OR FIRMWARE SUPPLIED TO THE LICENSEE. NOT WITHSTANDING THE LICENSEE MAY OWN THE MAGNETIC OR OTHER PHYSICAL MEDIA ON WHICH THE SOFTWARE OR FIRMWARE WAS ORIGINALLY SUPPLIED, OR HAS SUBSEQUENTLY BEEN RECORDED OR FIXED, IT IS A FUNDAMENTAL TERM OF THIS AGREEMENT THAT AT ALL TIMES TITLE AND OWNERSHIP OF THE SOFTWARE OR FIRMWARE, WHETHER ON THE ORIGINAL MEDIA OR OTHERWISE, SHALL REMAIN VESTED IN TAIT OR THIRD PARTIES WHO HAVE GRANTED LICENCES TO TAIT.

## Term and Termination

THIS LICENCE SHALL BE EFFECTIVE UNTIL TERMINATED IN ACCORDANCE WITH THE PROVISIONS OF THIS AGREEMENT. THE LICENSEE MAY TERMINATE THIS LICENCE AT ANY TIME BY DESTROYING ALL COPIES OF THE SOFTWARE OR FIRMWARE AND ASSOCIATED WRITTEN MATERIALS. THIS LICENCE WILL BE TERMINATED AUTOMATICALLY AND WITHOUT NOTICE FROM TAIT IN THE EVENT THAT THE LICENSEE FAILS TO COMPLY WITH ANY TERM OR CONDITION OF THIS AGREEMENT. THE LICENSEE AGREES TO DESTROY ALL COPIES OF THE SOFTWARE OR FIRMWARE AND ASSOCIATED WRITTEN MATERIALS IN THE EVENT OF SUCH TERMINATION.

## Limited Warranty

THE SOFTWARE OR FIRMWARE (INCLUDING OPEN SOURCE COMPONENTS) IS SUPPLIED BY TAIT AND ACCEPTED BY THE LICENSEE "AS IS" WITHOUT WARRANTY OF ANY KIND EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT BEING LIMITED TO ANY IMPLIED WARRANTIES AS TO MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. THE LICENSEE ACKNOWLEDGES THAT THE SOFTWARE OR FIRMWARE (INCLUDING OPEN SOURCE COMPONENTS) IS USED BY IT IN BUSINESS AND ACCORDINGLY TO THE MAXIMUM EXTENT PERMITTED BY LAW NO TERMS OR WARRANTIES WHICH ARE IMPLIED BY LEGISLATION SHALL APPLY TO THIS AGREEMENT. TAIT DOES NOT WARRANT THAT THE FUNCTIONS CONTAINED IN THE SOFTWARE OR FIRMWARE (INCLUDING OPEN SOURCE COMPONENTS) WILL MEET THE LICENSEE'S REQUIREMENTS OR THAT THE OPERATION OF THE SOFTWARE OR FIRMWARE (INCLUDING OPEN SOURCE COMPONENTS) WILL BE UNINTERRUPTED OR ERROR FREE.

## Exclusion of Liability

IN NO CIRCUMSTANCES SHALL TAIT BE UNDER ANY LIABILITY TO THE LICENSEE, OR ANY OTHER PERSON WHATSOEVER, WHETHER IN TORT (INCLUDING NEGLIGENCE), CONTRACT (EXCEPT AS EXPRESSLY PROVIDED IN THIS AGREEMENT), EQUITY, UNDER ANY STATUTE, OR OTHERWISE AT LAW FOR ANY LOSSES OR DAMAGES WHETHER GENERAL, SPECIAL, EXEMPLARY, PUNITIVE, DIRECT, INDIRECT OR CONSEQUENTIAL ARISING OUT OF OR IN CONNECTION WITH ANY USE OR INABILITY OF USING THE SOFTWARE OR FIRMWARE (INCLUDING OPEN SOURCE COMPONENTS).

THE LICENSEE'S SOLE REMEDY AGAINST TAIT WILL BE LIMITED TO BREACH OF CONTRACT AND TAIT'S SOLE AND TOTAL LIABILITY FOR ANY SUCH CLAIM SHALL BE LIMITED AT THE OPTION OF TAIT TO THE REPAIR OR REPLACEMENT OF THE SOFTWARE OR FIRMWARE OR THE REFUND OF THE PURCHASE PRICE OF THE SOFTWARE OR FIRMWARE.

## General

THE LICENSEE CONFIRMS THAT IT SHALL COMPLY WITH THE PROVISIONS OF LAW IN RELATION TO THE SOFTWARE OR FIRMWARE.

## Law and Jurisdiction

THIS AGREEMENT SHALL BE SUBJECT TO AND CONSTRUED IN ACCORDANCE WITH NEW ZEALAND LAW AND DISPUTES BETWEEN THE PARTIES CONCERNING THE PROVISIONS HEREOF SHALL BE DETERMINED BY THE NEW ZEALAND COURTS OF LAW. PROVIDED HOWEVER TAIT MAY AT ITS ELECTION BRING PROCEEDINGS FOR BREACH OF THE TERMS HEREOF OR FOR THE ENFORCEMENT OF ANY JUDGEMENT IN RELATION TO A BREACH OF THE TERMS HEREOF IN ANY JURISDICTION TAIT CONSIDERS FIT FOR THE PURPOSE OF ENSURING COMPLIANCE WITH THE TERMS HEREOF OR OBTAINING RELIEF FOR BREACH OF THE TERMS HEREOF.

## No Dealings

THE LICENSEE MAY NOT SUBLICENSE, ASSIGN OR TRANSFER THE LICENCE OR THE PROGRAM EXCEPT AS EXPRESSLY PROVIDED IN THIS AGREEMENT. ANY ATTEMPT OTHERWISE TO SUBLICENSE, ASSIGN OR TRANSFER ANY OF THE RIGHTS, DUTIES OR OBLIGATIONS HEREUNDER IS VOID.

## No Other Terms

THE LICENSEE ACKNOWLEDGES THAT IT HAS READ THIS AGREEMENT, UNDERSTANDS IT AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. THE LICENSEE FURTHER AGREES THAT SUBJECT ONLY TO ANY EXPRESS WRITTEN TERMS OF AGREEMENT TO THE CONTRARY BETWEEN TAIT AND THE LICENSEE THIS IS THE COMPLETE AND EXCLUSIVE STATEMENT OF THE AGREEMENT BETWEEN IT AND TAIT IN RELATION TO THE SOFTWARE OR FIRMWARE WHICH SUPERSEDES ANY PROPOSAL OR PRIOR AGREEMENT, ORAL OR WRITTEN AND ANY OTHER COMMUNICATIONS BETWEEN THE LICENSEE AND TAIT RELATING TO THE SOFTWARE OR FIRMWARE.